



NETAŞ Server

RAID User Guide (Genoa)

Version: R1.1

NETAŞ TELEKOMÜNİKASYON A.Ş
Yenişehir Mahallesi Osmanlı Bulvarı Aeropark Sitesi
B Blok No:11B İç Kapı No:40
Postcode: 34912
Tel: +90 (216) 522 20 00
URL: <https://destek.netas.com.tr>
E-mail: info@netas.com.tr

LEGAL INFORMATION

Copyright 2024 NETAŞ CORPORATION.

The contents of this document are protected by copyright laws and international treaties. Any reproduction or distribution of this document or any portion of this document, in any form by any means, without the prior written consent of NETAŞ CORPORATION is prohibited. Additionally, the contents of this document are protected by contractual confidentiality obligations.

All company, brand and product names are trade or service marks, or registered trade or service marks, of NETAŞ CORPORATION or of their respective owners.

This document is provided as is, and all express, implied, or statutory warranties, representations or conditions are disclaimed, including without limitation any implied warranty of merchantability, fitness for a particular purpose, title or non-infringement. NETAŞ CORPORATION and its licensors shall not be liable for damages resulting from the use of or reliance on the information contained herein.

NETAŞ CORPORATION or its licensors may have current or pending intellectual property rights or applications covering the subject matter of this document. Except as expressly provided in any written license between NETAŞ CORPORATION and its licensee, the user of this document shall not acquire any license to the subject matter herein.

NETAŞ CORPORATION reserves the right to upgrade or make technical change to this product without further notice.

Users may visit the NETAŞ technical support website <http://support.NETAŞ.com.cn> to inquire for related information.

The ultimate right to interpret this product resides in NETAŞ CORPORATION.

Statement on the Use of Third-Party Embedded Software:

If third-party embedded software such as Oracle, Sybase/SAP, Veritas, Microsoft, VMware, and Redhat is delivered together with this product of NETAŞ, the embedded software must be used as only a component of this product. If this product is discarded, the licenses for the embedded software must be void either and must not be transferred. NETAŞ will provide technical support for the embedded software of this product.

Revision History

Revision No.	Revision Date	Revision Reason
R1.1	2024-01-30	<ul style="list-style-type: none">● Updated "4 NETAŞ SmartROC 3100 RAID Controller Card".● Updated "5.1.2 Common Commands".
R1.0	2024-01-06	First edition.

Serial Number: SJ-20230907115354-011

Publishing Date: 2024-01-30 (R1.1)

Contents

1 Basic RAID Concepts.....	1
1.1 RAID Levels.....	1
1.1.1 RAID 0.....	1
1.1.2 RAID 1.....	2
1.1.3 RAID 1E.....	2
1.1.4 RAID 5.....	3
1.1.5 RAID 6.....	4
1.1.6 RAID 10.....	6
1.1.7 RAID 50.....	6
1.1.8 RAID 60.....	7
1.2 RAID Performance Comparison.....	8
1.3 RAID-Related Features.....	12
1.3.1 Disk Group and Virtual Disk.....	12
1.3.2 Fault Tolerance.....	12
1.3.3 Consistency Check.....	13
1.3.4 Hot Spare.....	13
1.3.5 Data Rebuild.....	14
1.3.6 Disk Status.....	15
1.3.7 Read/Write Policy for Virtual Disks.....	16
1.3.8 Data Protection Against a Power Supply Failure.....	18
1.3.9 Disk Striping.....	19
1.3.10 Disk Mirroring.....	20
1.3.11 Foreign Configuration.....	20
1.3.12 Disk Energy Saving.....	21
1.3.13 Disk Pass-Through.....	21
2 Applicable Server Models.....	22
3 NETAŞ SmartIOC 2100 RAID Controller Card.....	23
3.1 Capability Features.....	23
3.2 Initial Configuration (Legacy Mode).....	24
3.2.1 Starting the Configuration Utility.....	25
3.2.2 Creating a RAID Volume.....	26
3.2.3 Configuring a Boot Device.....	32

3.3 Initial Configuration (UEFI Mode).....	33
3.3.1 Starting the Configuration Utility.....	34
3.3.2 Creating a RAID Volume.....	38
3.4 Common Configurations (Legacy Mode).....	46
3.4.1 Querying RAID Volume Information.....	47
3.4.2 Creating a Hot Spare Disk.....	49
3.4.3 Deleting a RAID Volume.....	53
3.4.4 Deleting a Hot Spare Disk.....	56
3.4.5 Locating a Disk.....	59
3.4.6 Configuring a Pass-Through Disk.....	61
3.5 Common Configurations (UEFI Mode).....	66
3.5.1 Setting the Mode of a Port.....	67
3.5.2 Locating a Disk.....	73
3.5.3 Creating a Hot Spare Disk.....	86
3.5.4 Changing a Hot Spare Disk.....	93
3.5.5 Deleting a Hot Spare Disk.....	99
3.5.6 Configuring the Performance or Power Mode.....	106
3.5.7 Deleting a RAID volume.....	113
3.5.8 Deleting a Disk Group.....	121
3.5.9 Clearing RAID Configuration Information.....	126
3.5.10 Configuring a Pass-Through Disk.....	130
3.6 Typical Scenarios for Replacing a Disk (Legacy Mode).....	138
3.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk.....	138
3.6.2 Moving All Member Disks of a RAID 1 Volume.....	139
3.7 Typical Scenarios for Replacing a Disk (UEFI Mode).....	140
3.7.1 A RAID 0 Member Disk Fails.....	140
3.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails.....	140
3.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails.....	141
4 NETAŞ SmartROC 3100 RAID Controller Card.....	142
4.1 Capability Features.....	142
4.2 Initial Configuration (Legacy Mode).....	143
4.2.1 Starting the Configuration Utility.....	144
4.2.2 Creating a RAID Volume.....	145
4.2.3 Configuring a Boot Device.....	151

4.3 Initial Configuration (UEFI Mode).....	152
4.3.1 Starting the Configuration Utility.....	153
4.3.2 Creating a RAID Volume.....	157
4.4 Common Configurations (Legacy Mode).....	165
4.4.1 Querying RAID Volume Information.....	166
4.4.2 Creating a Hot Spare Disk.....	168
4.4.3 Deleting a RAID Volume.....	172
4.4.4 Deleting a Hot Spare Disk.....	175
4.4.5 Locating a Disk.....	178
4.4.6 Configuring a Pass-Through Disk.....	180
4.4.7 Enabling the Caching Function.....	185
4.5 Common Configurations (UEFI Mode).....	189
4.5.1 Setting the Mode of a Port.....	189
4.5.2 Locating a Disk.....	195
4.5.3 Creating a Hot Spare Disk.....	208
4.5.4 Changing a Hot Spare Disk.....	215
4.5.5 Deleting a Hot Spare Disk.....	221
4.5.6 Configuring the Performance or Power Mode.....	228
4.5.7 Deleting a RAID Volume.....	235
4.5.8 Deleting a Disk Group.....	243
4.5.9 Clearing RAID Configuration Information.....	248
4.5.10 Configuring a Pass-Through Disk.....	252
4.5.11 Enabling the Caching Function.....	260
4.6 Typical Scenarios for Replacing a Disk (Legacy Mode).....	273
4.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk.....	273
4.6.2 Moving All Member Disks of a RAID 1 Volume.....	274
4.7 Typical Scenarios for Replacing a Disk (UEFI Mode).....	275
4.7.1 A RAID 0 Member Disk Fails.....	275
4.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails.....	275
4.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails.....	276
5 Appendixes.....	277
5.1 ARCCONF CLI Tool.....	277
5.1.1 Downloading and Installing the ARCCONF Tool.....	277
5.1.2 Common Commands.....	279

5.2 Common Operations.....	307
5.2.1 Setting the Boot Mode to Legacy.....	307
5.2.2 Setting the Boot Mode to UEFI.....	312
Glossary.....	318

About This Manual

Purpose

This manual describes the features of various **RAID** controller cards ("RAID cards" for short) installed on NETAŞ servers, and the operations involved in initial configuration, common configuration and disk replacement.

Intended Audiences

This manual is intended for:

- Network planning engineers
- Network management engineers
- Maintenance engineers

What Is in This Manual

This manual contains the following chapters and appendixes.

Chapter 1, Basic RAID Concepts	Describes basic RAID-related concepts such as the RAID level, disk group, virtual disk, fault tolerance, and consistency check.
Chapter 2, Applicable Server Models	Describes the server models that this manual is applicable to.
Chapter 3, NETAŞ SmartIOC 2100 RAID Controller Card	Describes the capability features, initial configurations, common configurations, and typical disk replacement scenarios for a NETAŞ SmartIOC 2100 RAID controller card.
Chapter 4, NETAŞ SmartROC 3100 RAID Controller Card	Describes the capability features, initial configurations, common configurations, and typical disk replacement scenarios for a NETAŞ SmartROC 3100 RAID controller card.
Chapter 5, Appendixes	Describes the CLI tool ARCCONF for RAID controller cards, and VROC -based RAID configuration steps and common operations.

Conventions

This manual uses the following conventions.

	Notice: indicates equipment or environment safety information. Failure to comply can result in equipment damage, data loss, equipment performance degradation, environmental contamination, or other unpredictable results. Failure to comply will not result in personal injury.
---	---



Note: provides additional information about a topic.

Chapter 1

Basic RAID Concepts

Table of Contents

RAID Levels.....	1
RAID Performance Comparison.....	8
RAID-Related Features.....	12

1.1 RAID Levels


RAID refers to a disk array that combines multiple physical disks for the purpose of data redundancy.

It can provide higher storage performance, [I/O](#) performance and reliability than a single disk. Commonly used RAID levels include RAID 0, RAID 1, RAID 1E, RAID 5, RAID 6, RAID 10, RAID 50, and RAID 60.

1.1.1 RAID 0

RAID 0 is also called stripe or striping. [Figure 1-1](#) shows its data storage principle.

Figure 1-1 RAID 0 Data Storage Diagram



The storage principle of RAID 0 is to distribute sequential data (A0–A2, B0–B2, C0–C2, ...) to several member disks.

RAID 0 provides the highest storage performance among all RAID levels, because when the system receives a data request, multiple member disks in the RAID 0 array can concurrently execute the data request. This type of concurrent data operation can make full use of the bus bandwidth, remarkably boosting the overall disk read/write performance.


Because RAID 0 provides no data redundancy, data security cannot be guaranteed. Therefore, RAID 0 can only be used in scenarios where the requirements for [I/O](#) are high, but the requirements for data security are low.

RAID 0 requires at least one disk, and the data will be lost if the disk fails.

1.1.2 RAID 1

RAID 1 is also called mirror or mirroring, see [Figure 1-2](#).

Figure 1-2 RAID 1 Data Storage Diagram



Each working disk of the RAID 1 array has a corresponding mirrored disk, and a piece of sequential data (A0, A1, A2, ...) needs to be written into the working disk and the mirrored disk respectively, which is equivalent to automatic backup.

When the working disk of the RAID 1 array is faulty, the system automatically reads data from the mirrored disk.


RAID 1 requires at least two disks, and data is not lost if one disk fails.

RAID 1 provides high reliability but only a half of the total capacity. The disk usage is low.

Therefore, RAID 1 is applicable to the scenarios where high fault tolerance is required, such as finance.

1.1.3 RAID 1E

RAID 1E is an enhanced version of RAID 1, which integrates data mirroring and data striping, see [Figure 1-3](#).

Figure 1-3 RAID 1E Data Storage Diagram


Data striping and data backup of RAID 1E spread across all the member disks. Take two stripe groups (for example, A0, A1, A2 and A2, A1 and A0) as one unit. In each unit, the data in the previous stripe group is arranged continuously, and the next stripe group is the striped mirror of the previous stripe group. That is, the data in each member disk of the previous stripe group is moved rightwards one disk and written into each member disk of the next stripe group. The data of the last member disk is written into the first member disk.

RAID 1E requires at least three disks, and data is not lost if one disk fails. When a member disk of the RAID 1E array fails, the system transfers the read/write requests to other normal member disks for processing.

Compared with RAID 1, RAID 1E also uses the mirroring mode to store data, so its effective capacity is half of the total hard disk capacity. Because RAID 1E allows access to more member disks, it has stronger data recovery capability. However, each piece of data must be written at least twice, which reduces the disk write capability.

1.1.4 RAID 5

RAID 5 is a solution that balances storage performance, data security and storage costs, see [Figure 1-4](#).

Figure 1-4 RAID 5 Data Storage Diagram

RAID 5 uses the [CRC](#) mode to distribute sequential data (A0–A2, B0–B2, C0–C2, D0–D2, ...) and the corresponding parity data (VA, VD, ...) to different member disks respectively.

RAID 5 requires at least three disks, and data is not lost if one disk fails. If a member disk in the RAID 5 array is faulty, the data on the faulty member disk can be rebuilt from the data on other member disks in the array through the XOR operation.




For example, when the data block A0 is damaged, the recovery can be calculated with the following formula:

$$A0 = A1 \oplus A2 \oplus VA$$

RAID 5 can be used to process both a large or small amount of data. It features high speed, large capacity, and fault tolerance distribution. It is often used in various private [NAS](#) servers. RAID 5 can be regarded as a trade-off between RAID 0 and RAID 1.

1.1.5 RAID 6

On the basis of [RAID](#), RAID 6 is formed to further enhance data protection, see [Figure 1-5](#).

Figure 1-5 RAID 6 Data Storage Diagram

Like RAID 5, RAID 6 distributes sequential data (A0–A2, B0–B2, C0–C2, D0–D2, ...) and the corresponding parity data (VA, VD, ...) to different member disks respectively.

The difference is that on the basis of RAID 5, RAID 6 adds a second parity block (WA, WB, WC and WD,). The two independent check systems use different algorithms to implement double check and enhance fault tolerance. Therefore, when two member disks of the RAID 6 array are faulty, data security can also be guaranteed, achieving high reliability.

RAID 6 requires at least four disks, and data is not lost if two disks fail. If two member disks in a RAID 6 array are faulty, the data on the faulty member disks can be rebuilt from the data on other member disks in the array through the XOR (#) operation and the coefficient and XOR operation.



For example, when two data blocks A0 and A1 are damaged at the same time, you can recover them by using the following formula:

$$A0 = A1 \oplus A2 \oplus VA$$

$$A1 = (A0 \times K0 \oplus A2 \times K2 \oplus WA) / K1$$


In the above formula, K0, K1 and K2 are polynomial values in the Galois domain, and are known coefficients.

The read performance and fault tolerance performance of RAID 6 are higher, but more disk space is allocated for parity data. Therefore, compared with RAID 5, it has greater write performance loss and higher implementation costs.

1.1.6 RAID 10

RAID 10 is a combination of RAID 1 and RAID 0, see [Figure 1-6](#).

Figure 1-6 RAID 10 Data Storage Diagram



RAID 10 can be regarded as: Two member disks in a pair (Disk 0 and Disk 1, Disk 2 and Disk 3, ...) form a multiple RAID 1 volume. Multiple RAID 1 volumes form a RAID 0 array, and data is distributed on each RAID 1 volume in the form of RAID 0.


After receiving the [I/O](#) data requests, the system distributes the sequential data (A0, A1, B0, B1, C0, C1, ...) to two RAID 1 volumes for concurrent processing in accordance with the working mode of RAID 0. That is, the data is stored in the working disks Disk 0 and Disk 2. At the same time, in the manner of RAID 1, the system automatically copies data to mirrored disk Disk 1 when writing data into Disk 0, and copies data to the mirrored disk Disk 3 when writing data into Disk 2.

RAID 10 requires at least four disks, and data is not lost if two disks fail.

RAID 10 balances storage performance and data security. It not only provides data security (same as RAID 1) but storage performance (similar to RAID 0).

1.1.7 RAID 50

RAID 50 is a combination of RAID 5 and RAID 0, see [Figure 1-7](#).

Figure 1-7 RAID 50 Data Storage Diagram

One RAID 50 array consists of multiple RAID 5 volumes. At least six hard disks are required for RAID 50. Data is distributed on each RAID 5 volume in RAID 0 mode.

RAID 50 supports the features of both RAID 0 and RAID 5:


- Like RAID 0, data is partitioned into stripes and written into all the member disks at the same time.
- Like RAID 5, data security is guaranteed through parity bits that are evenly distributed on all the member disks.

With the redundancy function provided by RAID 5, if any disk in a RAID 5 volume is faulty, the array can operate properly and restore the data from the faulty disk. The replacement of the faulty disk does not affect services. Therefore, RAID 50 allows a single disk failure in multiple RAID 5 volumes at the same time, greatly improving the fault tolerance capability.

At the same time, RAID 50 inherits the high storage performance of RAID 0, and stores the data distributed in multiple RAID 5 volumes. It can process data concurrently, thus providing better read/write performance.

1.1.8 RAID 60

RAID 60 is a combination of RAID 6 and RAID 0, see [Figure 1-8](#).

Figure 1-8 RAID 60 Data Storage Diagram

One RAID 60 array consists of multiple RAID 6 volumes. At least eight hard disks are required for RAID 60. Data is distributed on each RAID 6 volume in RAID 0 mode.

RAID 60 supports the features of both RAID 0 and RAID 6:

- Like RAID 0, data is partitioned into stripes and written into all the member disks at the same time.
- Like RAID 6, RAID 60 ensures data security by using two parity blocks that are evenly distributed on all the member disks.

If two member disks of the RAID 6 array are faulty, with the redundancy provided by RAID 6, the array can operate properly and rebuild data of the faulty disk. The replacement of faulty disks does not affect services. Therefore, RAID 60 can maintain the security of data in the faulty disks when dual disks are faulty in multiple RAID 6 volumes at the same time.

In addition, RAID 60 inherits the high storage performance of RAID 0, and stores the data distributed in multiple RAID 6 volumes. It can process data concurrently, thus providing better read/write performance.

1.2 RAID Performance Comparison

Fault Tolerance Capabilities

For a description of the fault tolerance capability comparison between the commonly used RAID levels, refer to [Table 1-1](#). For the RAID containing multiple subgroups, RAID 10 and RAID 50 allow the number of faulty disks to be the same as the number of subgroups, but each subgroup must contain only one faulty disk. RAID 60 allows the number of faulty disks to be twice that of subgroups. Each subgroup can contain a maximum of two faulty disks.

Table 1-1 Fault Tolerance Capability Comparison Between Commonly Used RAID Levels

RAID Level	Fault Tolerance Capacity Description
RAID 0	It does not support fault tolerance. A fault in any member disk will affect data security.
RAID 1	It supports fault tolerance through data redundancy. When a member disk is faulty, the data on the corresponding mirrored disk can be used to run the system and rebuild the faulty disk.
RAID 1E	It supports fault tolerance through data redundancy. When a member disk is faulty, normal disks can be used to run the system and rebuild the faulty disk. If there are more than four member disks, two member disks are allowed to be faulty. However, the prerequisites are that the two faulty disks cannot be adjacent to each other, and the two faulty disks cannot be the first member disk and the last member disk.
RAID 5	It supports fault tolerance through the distributed parity data. When a member disk is faulty, the RAID controller card uses parity data to rebuild all the lost data.
RAID 6	It supports fault tolerance through the distributed parity data. When two member disks are faulty, the data on the normal member disks and the corresponding two sets of parity data can be used to calculate and rebuild the faulty disk.
RAID 10	It supports fault tolerance through data redundancy. Each RAID 1 volume allows one member disk to be faulty. The data in the corresponding mirrored disk in the group can be used to run the system and rebuild the faulty disk.
RAID 50	It supports fault tolerance through the distributed parity data. Each RAID 5 volume allows one member disk to be faulty. The data on normal disks and the corresponding one set of parity data can be used to calculate and rebuild the faulty disk.
RAID 60	It supports fault tolerance through the distributed parity data. Each RAID 6 volume allows two member disks to be faulty. The data on normal disks and the corresponding two sets of parity data can be used to calculate and rebuild the faulty disks.

I/O Performance

A RAID array can be used as an independent storage unit or multiple virtual units by the system. Because multiple disks can be accessed at the same time, the I/O performance for a RAID array is higher than that for a common disk. For a description of the I/O performance comparison between the commonly used RAID levels, refer to [Table 1-2](#).

Table 1-2 I/O Performance Comparison Between Commonly Used RAID Levels

RAID Level	I/O Performance Description

RAID 0	RAID 0 divides data into smaller data blocks and writes them into different disks. Because multiple disks can be read and written at the same time, RAID 0 improves the I/O performance.
RAID Level	I/O Performance Description
RAID 1	Because the disks in a RAID group exist in pairs, data must be written in two copies at the same time, occupying longer time and resources. As a result, the performance deteriorates.
RAID 1E	Each piece of data must be written at least twice, which reduces the disk write capability.
RAID 5	Because both common data and parity data is kept on member disks, each member disk can be read and written separately. Therefore, RAID 5 provides high data throughput.
RAID 6	RAID 6 needs to write two sets of parity data across member disks, which causes performance deterioration during write operations. RAID 6 is ideal in scenarios where high reliability, high response rate and high transmission rate are required to provide high data throughput, high data redundancy and high I/O performance.
RAID 10	With the high data transmission rate provided by the RAID 0 subgroup, RAID 10 performs well in data storage. The I/O performance is improved as the number of subgroups increases.
RAID 50	RAID 50 outperforms other RAID levels in the scenarios that require high reliability, high response rate and high transmission rate. The I/O performance is improved as the number of subgroups increases.
RAID 60	Its application scenarios are similar to those of RAID 50. However, because two sets of parity data need to be written into each member disk, its performance is deteriorated during write operations. Therefore, RAID 60 is not applicable to tasks that require writing massive data.

Available Capacity

For a description of the storage capacity comparison between the commonly used RAID levels, refer to [Table 1-3](#).

Table 1-3 Storage Capacity Comparison Between Commonly Used RAID Levels

RAID Level	Storage Capacity Description
RAID 0	In all RAID levels, RAID 0 provides the maximum storage capacity. Available capacity = minimum capacity of a member disk x number of member disks

RAID 1	Data must be written in two copies, causing high storage space consumption. Available capacity = minimum capacity of a member disk x number of member disks ÷ 2
RAID 1E	Two stripe groups are used as one unit, and the next stripe group is the striped mirror of the last stripe group, causing high storage space consumption. Available capacity = minimum capacity of a member disk x number of member disks ÷ 2
RAID Level	Storage Capacity Description
RAID 5	Parity data blocks are isolated from common data blocks. In general, parity data occupies the capacity of one member disk. Available capacity = minimum capacity of a member disk x (number of member disks - 1)
RAID 6	Two independent parity data blocks are isolated from common data blocks. In general, the parity data occupies the capacity of two member disks. Available capacity = minimum capacity of a member disk x (number of member disks - 2)
RAID 10	It consists of multiple RAID 1 volumes and has the same capacity as RAID 1. Available capacity = minimum capacity of a member disk x number of member disks ÷ 2
RAID 50	It consists of multiple RAID 5 volumes. Its capacity is related to the number of RAID 5 volumes. Available capacity = total capacity of all the RAID 5 volumes
RAID 60	It consists of multiple RAID 6 volumes. Its capacity is related to the number of RAID 6 volumes. Available capacity = total capacity of all the RAID 6 volumes

Performance Comparison Summary

Each RAID level has its advantages and disadvantages in terms of fault tolerance, I/O performance and available capacity. For the overall comparison of the performance indicators, refer to [Table 1-4](#).

Table 1-4 Performance Comparison Summary

RAID Level	Fault Tolerance Ca- pability	I/O Performance		Number of Required Disks	Disk Usage
		Read Per- formance	Write Per- formance		

RAID 0	Low	High	High	$N \geq 2$	100%
RAID 1	High	High	Medium	$2N (N \geq 1)$	50%
RAID 1E	High	High	Medium	$N \geq 3$	50%
RAID 5	Medium	High	Medium	$N \geq 3$	$(N-1)/N$
RAID 6	High	High	Medium	$N \geq 4$	$(N-2)/N$
RAID 10	High	Medium	Medium	$2N (N \geq 2)$	50%
RAID 50	High	High	High	$N \geq n \times M (n \geq 3, M \geq 2)$	$(N-M)/N$
RAID 60	High	High	High	$N \geq n \times M (n \geq 4, M \geq 2)$	$(N-2M)/N$

1. N is the total number of RAID member disks.
2. M is the number of RAID volumes.
3. n is the number of member disks in each volume.

1.3 RAID-Related Features

1.3.1 Disk Group and Virtual Disk

With the explosive growth of modern data centers, data service traffic is increasing day by day, resulting in higher requirements for data storage capacity and read/write speed of servers. As a result, common disks cannot meet these requirements. In this case, it is necessary to form multiple independent disks into a super-large disk group in a specific way to provide better storage performance, [I/O](#) performance and security.

A virtual disk is a continuous data storage unit divided based on an overall disk group. Virtual disks can be configured to have larger capacity, higher security, and more data redundancy than a single physical disk.

A virtual disk can be:

- A complete disk group
- Multiple complete disk groups
- Part of a disk group
- Parts of multiple disk groups (a part is divided from each disk group and they constitute a virtual disk)

Related conventions:

- A disk group ([DG](#) for short) is also called a drive group or array.

- A virtual disk is also called virtual drive ([VD](#) for short), volume or logical disk ([LD](#) for short).

1.3.2 Fault Tolerance

Fault tolerance means that data integrity and data processing capabilities are not affected when a disk error or disk fault occurs in a disk group.

Fault tolerance improves the disk system availability, guaranteeing system operation.

Therefore, fault tolerance is a very important feature in the fault recovery procedure.

[RAID](#) can use redundant data to restore the data errors occurring during the calculation or transmission to achieve fault tolerance. RAID 1, RAID 1E, RAID 5, RAID 6, RAID 10, RAID 50 and RAID 60 provide the fault tolerance capability. For the fault tolerance description at each level, refer to "[Fault Tolerance Capabilities](#)".



Note

RAID 0 does not provide fault tolerance. Once a disk fails, its data is lost.

1.3.3 Consistency Check

For [RAID](#) 1, RAID 5, RAID 6, RAID 10, RAID 50 and RAID 60 with the redundancy function, the RAID controller card calculates the data stored on the disks, and compares these data with the corresponding redundant data. If any inconsistency is found, an attempt is made to automatically fix the inconsistency and save the error information. It is recommended that a consistency check be performed at least once a month.



Note

Because RAID 0 does not provide the redundancy function, it does not support the consistency check.

1.3.4 Hot Spare

Hot Spare

Hot spare refers to the backup performed when the system is operating properly. The hot spare feature of the [RAID](#) controller card is implemented by hot spare and emergency spare.

Hot Spare Disk

A hot spare disk is an independent disk in the disk system. When a disk in a RAID group is faulty, the hot spare disk is automatically added to the RAID group to replace the faulty disk for rebuilding data and providing fault tolerance.

On RAID controller card management screens or CLI, an idle disk whose capacity is greater than or equal to that of a member disk in a RAID group and whose media type and interface are the same as those of the member disk can be specified as the hot spare disk of the RAID group.

The RAID controller card supports the following two types of hot spare disks:

- Global hot spare disk, which is shared by all the configured RAID groups of a RAID controller card. One RAID controller card can be configured with one or more global hot spare disks. If a member disk in any RAID group fails, the global hot spare disk can automatically replace the faulty disk.
- Dedicated hot spare disk, which is exclusive to a specific RAID group of a RAID controller card. Each RAID group can be configured with one or more dedicated hot spare disks. If a member disk in the specified RAID group fails, the dedicated hot spare disk can automatically replace the faulty disk.

A hot spare disk has the following features:

- The hot spare disk is only used for the RAID groups with redundancy, including RAID 1, RAID 1E, RAID 5, RAID 6, RAID 10, RAID 50 and RAID 60.
- The hot spare disk is only used to replace a faulty disk managed by the same RAID controller card.

Emergency Spare

The emergency spare function means that if a member disk in any RAID group with the redundancy function is faulty and no hot spare disk is specified, an idle disk managed by the RAID controller card automatically replaces the faulty member disk and rebuilds the data to avoid data loss.

Emergency spare requires that the capacity of the idle disk must be greater than or equal to that of the member disk, and the media type and interface of the idle disk must be the same as that of the member disk.

1.3.5 Data Rebuild

Description

If a faulty disk exists in a [RAID](#) group, you can use the data rebuild function of the RAID controller card to rebuild data in the faulty disk for a new disk. The data rebuild function is only used for the RAID arrays with redundancy, including RAID 1, RAID 5, RAID 6, RAID 10, RAID 50 and RAID 60.

The RAID controller card supports automatic data rebuild:

- If an available hot spare disk is specified for a RAID group, when a member disk is faulty, the hot spare disk automatically replaces the faulty disk and rebuilds the data.
- If no available hot spare disk is specified for a RAID group, when a member disk is faulty, an idle disk in the RAID group automatically replaces the faulty disk and rebuilds the data.



Note

The hot spare disk and idle disk used for data rebuild must meet the following requirements:

- The capacity is larger than or equal to the RAID member disk.
- The media type and interface are the same as those of the member disk.

If no hot spare disk is specified for a RAID group and no idle disk meets requirements, data can be rebuilt only after the faulty disk is replaced with a new one.

After the hot spare disk begins data rebuild, the faulty member disk is marked as removable. If the system is powered off during the data rebuild process, the RAID controller card continues the data rebuild task after the system is restarted.

Rebuild Rate

The rebuild rate is the proportion of **CPU** resources occupied by a data rebuild task to the overall CPU resources during the system operation. It can be set to 0%–100%.

- The value **0%** indicates that the data rebuild task is started only when there is no other task running in the system.
- The value **100%** indicates that the data rebuild task occupies all **CPU** resources.



Note

The rebuild rate can be set as required. It is recommended that you set a proper value based on the actual system conditions.

1.3.6 Disk Status

Physical Disk Status

For a description of the possible status of a physical disk managed by a **RAID** controller card, refer to [Table 1-5](#).

Table 1-5 Physical Disk Status

Status	Description
Online	Indicates that the disk is a member disk of a virtual disk and is online and can be used properly.

Status	Description
Unconfigured Good	Indicates that the disk is in normal status, but is not a member disk or a hot spare disk of a virtual disk.
Hot Spare	Indicates that the disk is set as a hot spare disk.
Failed	This status appears when an unrecoverable error occurs on a disk in Online or Hot Spare status.
Rebuild/Rebuilding	Indicates that the disk is rebuilding data to ensure the data redundancy and integrity of the virtual disk. In this case, the performance of the virtual disk is affected.
Unconfigured Bad	This status appears when an uninitialized disk or a disk in Unconfigured Good status has an unrecoverable error.
Missing	This status appears after the disk in the Online status is removed.
Offline	Indicates that the disk is a member disk of a virtual disk and is offline and can be used properly.
Shield State	Indicates the temporary status in which the physical disk is performing a diagnosis operation.
Copyback	Indicates that a new disk is replacing the hot spare disk.
Status	Description
Unsupport	Indicates that the specification of the disk exceeds the current specification of the RAID controller card.
Raw (Pass Through)	Indicates that the disk is a pass-through disk in HBA mode. For the concept of pass-through, refer to " 1.3.13 Disk Pass-Through ".
Ready	<p>Indicates that the disk in this status can be used to configure a RAID volume, which is applicable to the RAID mode and Mixed mode of the RAID controller card.</p> <ul style="list-style-type: none"> • In RAID mode, the connected disks can be used in the system only after they form a RAID volume, and the disks in Ready status are not reported to the OS. • In Mixed mode, the connected disks can be used directly or form a RAID volume, and the disks in Ready status are reported to the OS.
Predictive Failure	Indicates that the disk is about to change to the Failed status. The data on the disk needs to be backed up and the disk needs to be replaced.

Virtual Disk Status

For a description of the possible status of a virtual disk created under a RAID controller card, refer to [Table 1-6](#).

Table 1-6 Virtual Disk Status

Status	Description
Optimal	Indicates that the virtual disk is in good condition and all member disks are online.
Degraded	Indicates that the virtual disk is available but abnormal, and some member disks are faulty or offline.
Failed	Indicates that the virtual disk is faulty.
Partial Degraded	This status appears when the number of faulty or offline disks in the RAID group does not exceed the maximum number of faulty disks supported by the RAID array.
Offline	This status appears when the number of faulty or offline disks in the RAID group exceeds the maximum number of faulty disks supported by the RAID array.

1.3.7 Read/Write Policy for Virtual Disks

Overview

When creating a virtual disk, you need to define the data read/write policies to standardize subsequent data read and write operations on it.

Data Read Policy

"**Read Policy**" is generally displayed on the configuration screen. The [RAID](#) controller card supports the following two types of data read policies:

- **Read-ahead mode:** When a RAID controller card reads the required data from the virtual disk, it simultaneously reads the subsequent data and writes it into the cache. If a user needs to access the data, the data can be directly read from the cache to reduce the track seeking operation, save the response time, and improve the data read speed.



Notice

To use this policy, the RAID controller card must support data protection against a power supply failure. However, if the super capacitor is abnormal at this time, the data may be lost.

- Non-read-ahead mode: The RAID controller card reads data from the virtual disk only after receiving a data read command. It does not perform the read-ahead operation.

Data Write Policy

"**Write Policy**" is generally displayed on the configuration screen. The RAID controller card supports the following three types of data write policies:

- Write back: If this policy is used, when data needs to be written to a virtual disk, it is directly written into the cache. The RAID controller card refreshes the data to the virtual disk only when the written data is accumulated to a certain extent, achieving batch data write and improving the data write speed. After receiving all the transmitted data, the cache returns the data transmission completion signal to the host.



Notice

To use this policy, the RAID controller card must support data protection against a power supply failure. However, if the super capacitor is abnormal at this time, the data may be lost.

- Direct write: The RAID controller card directly writes data to the virtual disk without being cached. However, the write speed is low. After the virtual receives all the transmitted data, the RAID controller card returns the data transmission completion signal to the host.



Note

This policy does not require the RAID controller card to support data protection against a power supply failure. Even if the super capacitor fails, there is no impact.

- BBU-related write-back:
 - When the **BBU** of the RAID controller card is present and operates properly, the write operation from the RAID controller card to the virtual disk is transited through the cache (write-back mode).
 - When the BBU of the RAID controller card is not present or the BBU is faulty, the write operation from the RAID controller card to the virtual disk is automatically switched to the direct write mode without being cached.

1.3.8 Data Protection Against a Power Supply Failure

Protection Principle

The speed of writing data into the high-speed cache of a RAID controller card is greater than that of writing data into a disk. When the server writes a large amount of data, the high-speed cache of the RAID controller card can be used to improve system performance.

After the high-speed cache is enabled, the advantages and disadvantages are as follows:

- The write performance of the server is improved. When the write pressure on the server is reduced or the high-speed cache of the RAID controller card is to be full, data is written into a disk from the high-speed cache.
- The risk of data loss increases. When the server is powered off accidentally, the data in the high-speed cache of the RAID controller card will be lost.

To improve the high read/write performance of the server and ensure the data security in the high-speed cache of the RAID controller card, you can configure a super capacitor for the RAID controller card. In case of unexpected power failure of the server, the super capacitor is used to supply power to the RAID controller card, and data in the high-speed cache is written into the NAND flash in the super capacitor for storage.

Super Capacitor Power Calibration

Because protection against a power supply failure requires a super capacitor, the RAID controller card needs to record the discharge curve and the maximum power of the super capacitor to learn about the status of the super capacitor. In addition, to extend the lifespan of the super capacitor, the automatic calibration mode of the super capacitor is enabled on the RAID controller card by default.

The RAID controller card needs to keep the battery level of the super capacitor at a relatively stable value. Therefore, the battery level of the super capacitor is calibrated through the three-phase charging/discharging operations. The three-phase charging/discharging operations are as follows:

1. Charges the super capacitor with maximum power.
2. Automatically starts the calibration process to completely discharge the super capacitor.
3. Recharges the super capacitor to the maximum power.

The super capacitor has the following characteristics during the calibration process:

- The write policy of the RAID controller card is automatically adjusted to direct write mode to ensure data security.
- The write performance of the RAID controller card is low.
- The power calibration period depends on the charging and discharging speeds of the super capacitor.

1.3.9 Disk Striping


Basic Concepts

Disk striping means that the disk space is divided into multiple stripes in accordance with the specified size and data blocks are also divided in accordance with the stripe size when data is written. The specific concepts include the following:

- Stripe width: number of disks used in a disk group for striping.
- Stripe size of a disk group: total amount of data written at the same time on all member disks in the disk group by the RAID controller card.
- Stripe size of a disk: amount of data written into a single disk.

For example, a [RAID 0](#) group composed of four member disks divides the sequential data into 12 data blocks and writes them to each member disk in the way shown in [Figure 1-9](#).

Figure 1-9 Disk Striping Example



In the example RAID 0, suppose the size of each data block is 2 KB:

- The stripe width is the number of member disks, that is, 4.
- The stripe size of the disk group is the sum of 12 data blocks, that is, 24 KB.
- The stripe size of each disk is the sum of three data blocks, that is, 6 KB.

Feature

Because most disks have restrictions on the number of accesses ([I/O](#) operation per second) and data transmission rate (data volume per second), when multiple processes access a disk at the same time, the disk restriction may be triggered. Subsequent processes are suspended. Striping is a technology used to automatically balance the I/O load across multiple physical disks. By dividing a piece of sequential data into multiple data blocks and writing them into different disks, multiple processes can access different parts of the data at the same time. In addition, when a disk needs sequential access to data, it can obtain the maximum I/O parallel capability.

**Note**

This feature does not ensure data redundancy.

1.3.10 Disk Mirroring

Disk mirroring means that the same data is written into two disks at the same time when a data write task is executed, thus achieving 100% data redundancy. Because the data on the two disks is exactly the same, when one disk is faulty, the data will not be lost, and the system automatically switches from the faulty disk to the mirrored disk for data read and write.

Disk mirroring is applicable to [RAID 1](#) and [RAID 10](#). It brings a complete redundancy of 100%, but it is costly and the actual disk usage is only 50%, because each disk needs a backup disk during the mirroring process, see [Figure 1-10](#).

Figure 1-10 Disk Mirroring Example



Segment 1

Segment 1 Duplicated

Segment 2

Segment 2 Duplicated

Segment 3

Segment 3 Duplicated

Segment 4

Segment 4 Duplicated

1.3.11 Foreign Configuration

The foreign configuration is different from the configuration of the current **RAID** controller card, and is usually displayed as **Foreign Configuration** on the configuration screen.

In the following cases, the foreign configuration exists:

- The RAID configuration information exists in a physical disk newly installed on a server, and the RAID controller card identifies such information as a foreign configuration.
- After the RAID controller card of a server is replaced, the new RAID controller card identifies the existing RAID information as foreign configuration.
- After a member disk of a RAID group is hot swapped, the member disk is marked as carrying foreign configuration.

The detected foreign configuration can be processed in accordance with the actual server conditions:

- If the RAID information carried by the newly inserted disk does not meet the requirements of the current scenario, the configuration can be deleted.

- After the RAID controller card is replaced, if you want to use the previous configuration, you can import that configuration to apply it on the new RAID controller card.

1.3.12 Disk Energy Saving

A **RAID** controller card has the disk energy saving function, and can control disk rotation in accordance with the disk configurations and **I/O** activities. All rotary **SAS** and **SATA** disks support this function.

When the disk energy saving function is enabled, both idle disks and idle hot spare disks mounted under the RAID controller card are in energy saving status. When related operations (for example, creating a RAID volume, creating a hot spare disk, expanding a disk dynamically, and rebuilding a hot spare disk) are performed, the disk in energy saving status can be woken up.

1.3.13 Disk Pass-Through

Disk pass-through, namely, the **JBOD** function, also called transparent command transmission, is a data transmission mode that only ensures transmission quality without processing the command by the transmission device.

After the disk pass-through function is enabled, the **RAID** controller card can transparently transmit commands to the connected disk. If no RAID group is configured, user commands can be transparently transmitted to a disk, so that upper-layer service software or management software can access the disk.

For example, during the installation of the server operating system:

- For a RAID controller card that supports the disk pass-through function, you can use a disk mounted under the RAID controller card as the installation disk.
- For a RAID controller card that does not support the disk pass-through function, you can use only the virtual disk configured under the RAID controller card as the installation disk.

Chapter 2

Applicable Server Models

This manual applies to NETAŞ NCS6722A N4 rack servers developed based on the **Genoa** platform.

Chapter 3

NETAŞ SmartIOC 2100

RAID Controller Card

Table of Contents

Capability Features.....	23
Initial Configuration (Legacy Mode).....	24
Initial Configuration (UEFI Mode).....	33
Common Configurations (Legacy Mode).....	46
Common Configurations (UEFI Mode).....	66
Typical Scenarios for Replacing a Disk (Legacy Mode).....	138

Capability Item	Capability Parameter
Product form	Mezz card
Controller chip	PMC PM8238
Host interface	PCIe 3.0x8

SAS interface	12 Gb SAS
---------------	------------------

[Typical Scenarios for Replacing a Disk \(UEFI Mode\)](#)..... 140

A **NETAŞ** SmartROC 2100 **RAID** controller card is integrated with the **BIOS** configuration utility. By using the program, you can configure the disks that are supported by the **NETAŞ** SmartROC 2100 **RAID** controller card to a **RAID** volume of a specific level.



Note

The operation screens of the **BIOS** configuration utility displayed in this chapter are for reference only, and may not be the same as the actual ones.

3.1 Capability Features

For a description of the capabilities of a **NETAŞ** SmartIOC 2100 **RAID** controller card, refer to [Table 3-1](#).


Table 3-1 Descriptions of the Capabilities of a **NETAŞ SmartIOC 2100 **RAID** Controller Card**

Capability Item	Capability Parameter
Number of ports	16+2
Drive interface	SAS and SATA
Drive type	HDD and SSD
Whether drives are hot swappable	Supported
Maximum number of RAID groups	8
Number of drives	238
RAID level	RAID 0, RAID 1, RAID 10, RAID 5
JBOD mode	Supported
Cache	None
Cache protection	None
Out-of-band management	Supported
Consistency check/verification and fix	Supported

Online capacity expansion	Supported
Online RAID level migration	Supported
Automatic rebuild	Supported
Manufacturer tool support	arcconf

3.2 Initial Configuration (Legacy Mode)

Figure 3-1 shows the initial configuration flow of a [NETAŞ SmartIOC 2100 RAID controller card](#).

Figure 3-1 Initial Configuration Flow of a NETAŞ SmartIOC 2100 RAID Controller Card

3.2.1 Starting the Configuration Utility

Abstract

This procedure describes how to start the **BIOS** configuration utility of a NETAŞ SmartIOC 2100 **RAID** controller card to log in to the management screen and complete the subsequent initial and common configurations.

Prerequisite

The boot mode is already set to **Legacy** in **BIOS**. For details, refer to "[5.2.1 Setting the Boot Mode to Legacy](#)".

Steps


1. Start the server system.
2. During the **POST** process, press **Ctrl+A** to start the **BIOS** configuration utility of the NETAŞ SmartIOC 2100 RAID controller card. The screen as shown in [Figure 3-2](#) is displayed.

Figure 3-2 BIOS Configuration Utility Screen



3. In the **Options** area, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Configuration Menu** screen is displayed, see [Figure 3-3](#).

Figure 3-3 Configuration Menu Screen



3.2.2 Creating a RAID Volume

Abstract

You can create **RAID** volumes at different levels as required.

The procedures for creating RAID volumes at different levels are similar. This procedure uses a RAID 0 volume in legacy mode as an example.

Prerequisite

Sufficient **SATA** and **SAS** disks are installed on the server.

Context

For a description of the number of disks required to create a RAID volume, refer to [Table 3-2](#).


Table 3-2 Number of Disks Required for Creating a RAID Volume

RAID Level	Description
RAID 0	RAID 0 requires at least one disks.
RAID 1	RAID 1 requires at least two disks. Disks with different capacities can be used in a RAID 1 volume, but the logical capacity of each member disk depends on the space of the disk with the smallest capacity.
RAID 5	RAID 5 requires at least three disks.
RAID 6	RAID 6 requires at least four disks.
RAID 10	RAID 10 requires at least four disks. A RAID 10 volume consists of at least two RAID 1 volumes. For example, if there are four disks to be used in RAID 10 mode, you need to add them to two drive groups, each of which is mounted with two disks in RAID 1 mode.
RAID 50	RAID 50 requires at least six disks. A RAID 50 volume consists of at least two RAID 5 volumes. For example, if there are six disks to be used in RAID 50 mode, you need to add them to two drive groups, each of which is mounted with three disks in RAID 5 mode.
RAID 60	RAID 60 requires at least eight disks. A RAID 60 volume consists of at least two RAID 6 volumes. For example, if there are eight disks to be used in RAID 60 mode, you need to add them to two drive groups, each of which is mounted with four disks in RAID 6 mode.

Steps


1. On the **Configuration Menu** screen, use the arrow keys to select **Create Array**, and then press **Enter**. On the displayed **Select drives to create Array** screen, all the disks that can be used to create a RAID volume are displayed, see [Figure 3-4](#).

Figure 3-4 Select Drives to Create Array Screen



2. Use the arrow keys to select the disks to be used to create a RAID volume, and then press **Insert** to add these disks to the **Selected Drives** list, see [Figure 3-5](#).

Figure 3-5 Selected Drives List




Note

- The disks for creating a RAID volume must be of the same type. It is forbidden to select disks with interface types such as **SATA** and **SAS** at the same time.
- Press the **Delete** key to delete the selected disk from the **Selected Drives** list.

3. Press **Enter**. The **Create Logical Drive** screen is displayed, see [Figure 3-6](#).

Figure 3-6 Create Logical Drive Screen



4. Use **Tab/Tab+Shift** to select the parameters that you want to modify. In the displayed operation box, use the arrow keys to select the related parameters, and then press **Enter** for confirmation. For a description of the parameters on the **Create Logical Drive** screen, refer to [Table 3-3](#).

Table 3-3 Descriptions of Parameters on the Create Logical Drive Screen


Parameter	Description
RAID Level	Sets a RAID standard, for example, RAID 0(Stripe) .
Logical Drive Name	Sets the RAID volume name, for example, "0".
Strip/Full Stripe Size	<p>The stripe size should be equal to the size of average disk IO requests generated by server applications. In the optimum status, only one IO operation is executed for each IO request. The recommended stripe size configurations are as follows:</p> <ul style="list-style-type: none"> For a Web server, 8 KB is recommended. For a groupware server (such as an email server), 16 KB is recommended. For a database server, 16 KB or 32 KB is recommended. For a file server, 32 KB or 64 KB is recommended For a video file server, 64 KB, 128 KB, or 256 KB is recommended.

Parity Group Count	Configures logical-device parity groups in accordance with the number of physical devices in the array. It is not applicable to all RAID levels.
Parameter	Description
Build Method	<p>Sets the RAID initialization method, which is used to determine how the logical devices prepare for read and write, and how long the initialization takes.</p> <ul style="list-style-type: none"> ● default: When the logical devices can be accessed by the operating system, parity blocks are initialized at the back end. A lower RAID level can achieve faster parity initialization. ● RPI: The data and parity blocks at the front end are overwritten. Before the parity initialization procedure is completed, logical devices remain invisible and unavailable to the operating system. All parity groups are initialized in parallel, but the initialization of a single parity group (RAID 5) is faster. The RAID level does not affect the performance during the RAID initialization. ● Not Applicable: unavailable. <p>Keep the default configuration unless otherwise specified.</p>
Size	<p>Displays the storage size of the disk array in accordance with the total storage space of the disks added to the disk array.</p> <p>By default, the RAID created uses all the available disk space.</p>
Acceleration Method	<p>Sets the caching mode for the RAID volume.</p> <ul style="list-style-type: none"> ● IO Bypass: This option is valid only when the RAID logical volume is formed by SSDs. ● Controller Cache: enables controller cache optimization. The read cache and write cache are used at the same time. ● None: disables the controller cache. Neither IO Bypass nor Controller Cache is used. <p>Keep the default configuration unless otherwise specified.</p>

5. Use **Tab** to select **Done**, and then press **Enter** to create the RAID volume, see [Figure 3-7](#).

Figure 3-7 Creating a RAID Volume

6. The RAID volume is created successfully, see [Figure 3-8](#). Press any key to return to the **Configuration Menu** screen.

Figure 3-8 RAID Volume Created Successfully

3.2.3 Configuring a Boot Device

Abstract

After a [RAID](#) volume is created, if you need to install an operating system on the RAID volume, and there are multiple RAID volumes on the RAID controller card, you must set the RAID volume as a boot device.


Prerequisite

A RAID volume is created successfully. For details, refer to “[3.2.2 Creating a RAID Volume](#)”.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** page is displayed, see [Figure 3-9](#).

Figure 3-9 List of Arrays Screen



2. Use the arrow keys to select the array where the RAID volume to be set as a boot device is located, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 3-10](#).


Figure 3-10 List of Logical Drives Screen

3. Select the RAID volume to be booted first, and then press **Ctrl+P** to configure it as the first boot device, see [Figure 3-11](#).

Figure 3-11 Configuring a Boot Device

3.3 Initial Configuration (UEFI Mode)

[Figure 3-12](#) shows the initial configuration flow of a NETAŞ SmartIOC 2100 RAID controller card.

Figure 3-12 Initial Configuration Flow of a NETAŞ SmartIOC 2100 RAID Controller Card

Note

- The SmartIOC 2100 RAID controller card does not support the boot disk configuration in [UEFI](#) mode.
- The SmartIOC 2100 RAID controller card does not support the co-existence of configurations in both UEFI and legacy modes. If the mode is switched from UEFI to legacy, the configuration in UEFI mode must be cleared. Otherwise, the normal operation of the RAID controller card is affected.

3.3.1 Starting the Configuration Utility

Abstract


This procedure describes how to start the [BIOS](#) configuration utility of a NETAŞ SmartIOC 2100 [RAID](#) controller card to log in to the management screen and complete the subsequent initial and common configurations.

Prerequisite


The boot mode is already set to [UEFI](#) in [BIOS](#). For details, refer to "[5.2.2 Setting the Boot Mode to UEFI](#)".

Steps

1. Start the server system.
2. During the [POST](#) process, press **F2/DEL**. The **Aptio Setup** screen is displayed, see [Figure 3-13](#).

Figure 3-13 Aptio Setup Screen

3. Use the arrow keys to select **Advanced**, and then press **Enter**. The **Advanced** screen is displayed, see [Figure 3-14](#).

Figure 3-14 Advanced Screen

4. Use the arrow keys to select **NETAŞ SmartIOC2100 RM24x V2.54**, and press **Enter**. The controller management screen is displayed, see [Figure 3-15](#).

Figure 3-15 Controller Management Screen

For a description of the functions of the menus on the controller management screen, refer to [Table 3-4](#).

Table 3-4 Functions of Menus on the Controller Management Screen

Menu	Function Description
Controller Information	Displays the basic information, firmware, current temperature, and port configuration of the controller.
Configure Controller Settings	Provides advanced configuration options for the controller.
Array Configuration	Creates an array or RAID.
Disk Utilities	Displays the list of disk devices mounted under the controller as well as the basic disk information. It allows you to turn on the disk location indicator, erase disk data and upgrade the firmware.
Set Bootable Device(s) for Legacy Boot Mode	Configures, or clears the primary and secondary boot disks.

Administration	Allows the controller administrator to perform operations, such as upgrading the firmware and restoring factory defaults.
----------------	---

3.3.2 Creating a RAID Volume

Abstract

You can create **RAID** volumes at different levels as required.

The procedures for creating RAID volumes at different levels are similar. This procedure uses a RAID 1 volume in **UEFI** mode as an example.

Prerequisite

- Sufficient **SATA** and **SAS** disks are installed on the server.
- The port mode for the disks to be connected is already set. For details, refer to "[3.5.1 Setting the Mode of a Port](#)".

Context

For a description of the number of disks required to create a RAID volume, refer to [Table 3-5](#).

Table 3-5 Number of Disks Required for Creating a RAID Volume


RAID Level	Description
RAID 0	RAID 0 requires at least one disks.
RAID 1	RAID 1 requires at least two disks. Disks with different capacities can be used in a RAID 1 volume, but the logical capacity of each member disk depends on the space of the disk with the smallest capacity.
RAID 5	RAID 5 requires at least three disks.
RAID 6	RAID 6 requires at least four disks.
RAID 1+0	RAID 1+0 requires at least four disks. A RAID 1+0 volume consists of at least two RAID 1 volumes. For example, if there are four disks to be used in RAID 1 +0 mode, you need to add them to two drive groups, each of which is mounted with two disks in RAID 1 mode.
RAID 50	RAID 50 requires at least six disks. A RAID 50 volume consists of at least two RAID 5 volumes. For example, if there are six disks to be used in RAID 50 mode, you need to add them to two drive groups, each of which is mounted with three disks in RAID 5 mode.

RAID 60	<p>RAID 60 requires at least eight disks.</p> <p>A RAID 60 volume consists of at least two RAID 6 volumes. For example, if there are eight disks to be used in RAID 60 mode, you need to add them to two drive groups, each of which is mounted with four disks in RAID 6 mode.</p>
---------	---


Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-16](#).

Figure 3-16 Array Configuration Screen



2. Use the arrow keys to select **Create Array**, and then press **Enter**. In the displayed disk list, all the disks that can be used to create a RAID volume are displayed, see [Figure 3-17](#).

Figure 3-17 Viewing the Disk List

3. Select the disk to be added to the Array disk group, and then press **Enter** to set the disk port to **Enabled** status, see [Figure 3-18](#).

Figure 3-18 Confirming the Configuration

The disks for creating a RAID volume must be of the same type. It is forbidden to select disks with interface types such as **SATA** and **SAS** at the same time.


4. Use the arrow keys to select **Proceed to Next Form**, and then press **Enter**. The screen for creating RAID is displayed, see [Figure 3-19](#).

Figure 3-19 Creating RAID




5. Use the arrow keys to select **RAID Level**, and then press **Enter**. From the displayed shortcut menu, select the desired RAID level, see [Figure 3-20](#).

Figure 3-20 Selecting a RAID Level



6. Use the arrow keys to select **Proceed to Next Form**, and press **Enter**. The screen for setting RAID logical volumes is displayed, see [Figure 3-21](#).

Figure 3-21 Setting RAID Logical Volumes

7. Use the arrow keys to select the parameters that you want to modify. In the displayed operation boxes, configure the related parameters. For a description of the parameters for setting a logical volume, refer to [Table 3-6](#).

Table 3-6 Parameter Descriptions for Logical Volume Configuration

Parameter	Description
Logical Drive Label	Sets the name of the RAID logical volume, for example, "Logical Drive 1".

Strip Size/Full Strip Size	<ul style="list-style-type: none"> Strip Size indicates the size of the current stripe. The stripe size should be equal to the size of average disk IO requests generated by server applications. In the optimum status, only one IO operation is executed for each IO request. The size can be 16 KiB, 32 KiB, 64 KiB, 128KiB, 512 KiB, or 1024 KiB. The default value is 256 KiB. The recommended stripe size configurations are as follows: <ul style="list-style-type: none"> For a Web server, 8 KiB is recommended. For a groupware server (such as an email server), 16 KiB is recommended. For a database server, 16 KiB or 32 KiB is recommended. For a file server, 32 KiB or 64 KiB is recommended. For a video file server, 64 KiB, 128 KiB, or 256 KiB is recommended.
Parameter	Description
	<ul style="list-style-type: none"> Full Strip Size indicates the total size of all stripes. When you set Strip Size, the system automatically calculates Full Stripe Size.
Size	<p>Displays the storage size of the RAID volume in accordance with the total storage space of the disks added to the RAID volume.</p> <p>By default, all available space is used to create a RAID logical volume. To create multiple RAID logical volumes, you can define the size of the volumes.</p>
Unit Size	Select the unit (MiB/GiB/TiB) of the logical drive.
Acceleration Method	<p>Sets the caching mode for the RAID volume.</p> <ul style="list-style-type: none"> IO Bypass: This option is valid only when the RAID logical volume is formed by SSDs. Controller Cache: enables controller cache optimization. The read cache and write cache are used at the same time. None: disables the controller cache. Neither IO Bypass nor Controller Cache is used. <p>Keep the default configuration unless otherwise specified.</p>

8. Use the arrow keys to select **Submit Changes**, and press **Enter**. The RAID volume is created successfully, see [Figure 3-22](#).

Figure 3-22 RAID Volume Created Successfully

9. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.4 Common Configurations (Legacy Mode)

By using the **BIOS** configuration utility, you can configure and maintain a created **RAID** volume. For a description of the common operations on a SmartIOC 2100 RAID controller card in legacy mode, refer to [Table 3-7](#).

Table 3-7 Common Operations on a SmartIOC 2100 RAID Controller Card

Common Operation	Description
Querying RAID volume information	Refer to " 3.4.1 Querying RAID Volume Information ".
Creating a hot spare disk	Refer to " 3.4.2 Creating a Hot Spare Disk ".
Deleting a RAID volume	Refer to " 3.4.3 Deleting a RAID Volume ".
Deleting a hot spare disk	Refer to " 3.4.4 Deleting a Hot Spare Disk ".

Locating a disk	Refer to " 3.4.5 Locating a Disk ".
Common Operation	Description
Configuring a pass-through disk	Refer to " 3.4.6 Configuring a Pass-Through Disk ".

3.4.1 Querying RAID Volume Information

Abstract

This procedure describes how to query the **RAID** information created on a SmartIOC 2100 RAID controller card, such as the RAID volume status and member disk status.


Prerequisite

A RAID volume is created successfully. For details, refer to "[3.2.2 Creating a RAID Volume](#)".


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 3-23](#).


Figure 3-23 List of Arrays Screen




2. Select the RAID volume whose properties you want to view, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 3-24](#).

Figure 3-24 List of Logical Drives Screen

3. Press **Enter**. In the displayed **Logical Drive Details** dialog box, view the property information about the RAID volume, see [Figure 3-25](#).

Figure 3-25 Logical Drive Details Dialog Box

4. (Optional) To view the member disk information, press **Ctrl+D**. The **Array Member Drives** dialog box is displayed, see [Figure 3-26](#).

Figure 3-26 Array Member Drives Dialog Box

3.4.2 Creating a Hot Spare Disk

Abstract

A hot spare disk improves the data security of a [RAID](#) array. For a description of the hot spare disk types supported by a SmartIOC 2100 [RAID](#) controller card, refer to [Table 3-8. Table 3-8 Hot Spare Disk Types](#)

Type	Description
Dedicated	<ul style="list-style-type: none"> This type of hot spare disks is exclusive to the specified one or more disk groups of a RAID controller card. One or more hot spare disks can be created for each disk group. When a disk in a disk group is faulty, a dedicated hot spare disk temporarily takes over the faulty disk.
Auto Replace	<ul style="list-style-type: none"> This type of hot spare disks provides the hot standby function for a disk group of a RAID controller card. One or more hot spare disks can be created for each disk group. When a disk in a disk group is faulty, a hot spare disk of this type automatically replaces the faulty disk.

Prerequisite

There are sufficient idle disks on the server.

Context


When creating a hot spare disk, pay attention to the following points:

- Multiple hot spare disks can be created for a disk group, but only one type of hot spare disk can be set at a time. That is, either **Dedicated** or **Auto Replace** is specified.
- An idle disk can be set as a hot spare disk. The disk that has been used to create a RAID volume cannot be set as a hot spare disk.
- The hot spare disk must be of the same type as that of any member disk in the corresponding disk group. That is, all of them are **SATA** disks or **SAS** disks, and the hot spare disk's capacity must not be less than the maximum capacity of the member disks.
- Disk groups at all levels except RAID 0 support hot spare disks.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 3-27](#).


Figure 3-27 List of Arrays Screen



2. Use the arrow keys to select the RAID volume for which you want to configure a hot spare disk, and press **Ctrl+S**. The **Select Hotspare Drives** screen is displayed, see [Figure 3-28](#).


Figure 3-28 Select Hotspare Drives Screen

3. Use the arrow keys to select the idle disk to be set as a hot spare disk, and then press **Insert** to add the disk to the **Selected Drives** list, see [Figure 3-29](#).


Figure 3-29 Selected Drives Screen

Press the **Delete** key to delete the selected disk from the **Selected Drives** list.

4. Press **Enter**. A confirmation dialog box is displayed, see [Figure 3-30](#).

Figure 3-30 Confirmation Dialog Box


5. At the cursor in the confirmation dialog box, enter Y. The **Select Spare Type** screen is displayed, see [Figure 3-31](#).

Figure 3-31 Select Spare Type Screen

6. Use the arrow keys to select the type of hot spare disk to be created, and then press **Enter** for confirmation, see [Figure 3-32](#).

Figure 3-32 Select Spare Type Screen

7. Use **Tab** to select **Done**, and then press **Enter** to create the hot spare disk, see [Figure 3-33](#).

Figure 3-33 Creating a Hot Spare Disk

3.4.3 Deleting a RAID Volume

Abstract

When a server no longer needs a **RAID** volume, you can delete the RAID volume to release the disk space.



Notice

The data that is lost during deletion of the RAID volume cannot be restored. Therefore, you must make sure that you have backed up important data before deleting the volume.


Prerequisite

A RAID volume is created successfully. For details, refer to “[3.2.2 Creating a RAID Volume](#)”.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 3-34](#).


Figure 3-34 List of Arrays Screen




2. Use the arrow keys to select the array where the RAID volume to be deleted is located, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 3-35](#).

Figure 3-35 List of Logical Drives Screen

3. Use the arrow keys to select the RAID volume to be deleted, and press **Delete**. A warning dialog box is displayed, see [Figure 3-36](#).

Figure 3-36 Warning Dialog Box

4. At the cursor in the warning dialog box, enter **Y** to delete the selected hot spare disk, see [Figure 3-37](#).

Figure 3-37 Deleting a RAID Volume

3.4.4 Deleting a Hot Spare Disk

Abstract


When the number of disks of a server cannot meet the requirements, you can delete an existing hot spare disk and restore it to a common disk.

Prerequisite

A hot spare disk is already created. For details, refer to “[3.4.2 Creating a Hot Spare Disk](#)”.

Steps


1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 3-38](#).

Figure 3-38 List of Arrays Screen

2. Use the arrow keys to select the array where the hot spare disk to be deleted is located, and press **Delete**. The **Select Hotspare drives** screen is displayed, see [Figure 3-39](#).


Figure 3-39 Select Hotspare Drives Screen

3. Use the arrow keys to select the hot spare disk to be deleted, and then press **Insert** to add the disk to the **Selected Drives** list, see [Figure 3-40](#).

Figure 3-40 Selected Drives List**Note**

Press the **Delete** key to delete the selected disk from the **Selected Drives** list.

4. Press **Enter**. A confirmation dialog box is displayed, see [Figure 3-41](#).

Figure 3-41 Confirmation Dialog Box

5. At the cursor in the confirmation dialog box, enter **Y** to delete the selected hot spare disk, see [Figure 3-42](#).

Figure 3-42 Deleting a Hot Spare Disk

3.4.5 Locating a Disk


Abstract

After the indicator of a disk is lit, you can locate the disk so that you can easily replace or maintain it.

Steps

1. In the **Options** area on the **BIOS** configuration utility screen, use the arrow keys to select **Disk Utilities**, and then press **Enter**. The **Select Disks and press <Enter>** screen is displayed, see [Figure 3-43](#).


Figure 3-43 Select Disks and Press <Enter> Screen



Arrow keys to move cursor, <Enter> to select option, <Esc> to exit (*=default)

2. Use the arrow keys to select the disk to be located, and then press **Enter**. A function menu is displayed, see [Figure 3-44](#).


Figure 3-44 Function Menu



Arrow keys to move cursor, <Enter> to select option, <Esc> to exit (*=default)

3. Use the arrow keys to select **Identify Device**, and then press **Enter**. A prompt message is displayed, see [Figure 3-45](#). At this time, the status indicator of the hard disk is lit up solid blue.

Figure 3-45 Disk Indicator Lit



4. Press any key to go out the disk indicator. The disk locating ends.

3.4.6 Configuring a Pass-Through Disk

Abstract

When the mode of the ports of a SmartIOC 2100 [RAID](#) controller card is set to [HBA](#), the hard disks connected to these ports can be configured as pass-through disks.


Context

The port modes are described as follows:

- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.
- In mixed mode, the connected disks support both RAID and HBA mode.
 - The RAID mode is applicable to the disks that have been used to create a RAID volume.
 - The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.

Steps

1. In the **Options** area on the **BIOS** configuration utility screen, use the arrow keys to select **Controller Details**, and then press **Enter**. The controller details are displayed. The value of **Controller Mode** is **MIXED**, see **Figure 3-46**.

Figure 3-46 Controller Details


2. Press **ESC** to return to the BIOS configuration screen. Use the arrow keys to select **Configure Controller Settings** and press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 3-48](#).

Figure 3-47 Configure Controller Settings Screen

3. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**. The **Configure Controller Port Mode** screen is displayed, see [Figure 3-48](#).

Figure 3-48 Configure Controller Port Mode Screen

4. Use the arrow keys to select the port whose connected disk is not used to create a RAID volume, and press **Enter**. In the displayed dialog box, set the port mode to **HBA**, see [Figure 3-50](#).

Figure 3-49 Setting the Port Mode to HBA

5. (Optional) If the connected disk is already used to create a RAID volume, set the port mode to **MIXED**, see [Figure 3-50](#).

Figure 3-50 Setting the Port Mode to MIXED**Note**

The mode of the ports whose connected disks are already used to create a RAID volume cannot be set to HBA.

6. Set the port mode as required, and then press **Esc** to exit. In the displayed dialog box, select **Yes** to save the configuration, see [Figure 3-51](#).

Figure 3-51 Saving the Configuration


7. Wait until a configuration success message is displayed, see [Figure 3-52](#).

Figure 3-52 Successful Configuration



8. Press **Esc** multiple times until the **Exit Utility** dialog box is displayed, see [Figure 3-53](#).


Figure 3-53 Exit Utility Dialog Box



9. In the **Exit Utility** dialog box, select **NO**, and then press **Enter**. The BIOS configuration utility screen is displayed, see [Figure 3-54](#).

Figure 3-54 BIOS Configuration Utility Screen

10. Use the arrow keys to select **Controller Details**, and then press **Enter**. The controller details are displayed, see [Figure 3-55](#). The value of **Controller Mode** is **HBA**.

Figure 3-55 Controller Details

3.5 Common Configurations (UEFI Mode)

By using the **BIOS** configuration utility, you can configure and maintain a created **RAID** volume. For a description of the common operations on a SmartIOC 2100 RAID controller card in **UEFI** mode, refer to [Table 3-9](#).

Table 3-9 Common Operations on a SmartIOC 2100 RAID Controller Card

Common Operation	Description
Setting a port mode	Refer to " 3.5.1 Setting the Mode of a Port ".
Locating a disk	Refer to " 3.5.2 Locating a Disk ".
Creating a hot spare disk	Refer to " 3.5.3 Creating a Hot Spare Disk ".
Changing a hot spare disk	Refer to " 3.5.4 Changing a Hot Spare Disk ".
Deleting a hot spare disk	Refer to " 3.5.5 Deleting a Hot Spare Disk ".
Configuring the power mode	Refer to " 3.5.6 Configuring the Performance or Power Mode ".
Deleting a RAID volume	Refer to " 3.5.7 Deleting a RAID volume ".
Deleting a disk group	Refer to " 3.5.8 Deleting a Disk Group ".
Clearing RAID configuration information	Refer to " 3.5.9 Clearing RAID Configuration Information ".
Configuring a pass-through disk	Refer to " 3.5.10 Configuring a Pass-Through Disk ".

3.5.1 Setting the Mode of a Port

Abstract

A SmartIOC 2100 [RAID](#) controller card supports four port modes: RAID, [HBA](#), mixed, and independent. Before adding the disk corresponding to a port to a RAID logical volume, you must check the port mode.

The SmartIOC 2100 RAID controller card supports setting the port mode in the following two ways:

- Setting the mode of all ports
- Setting the mode of a single port

Context

The port modes are described as follows:

- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.
- In mixed mode, the connected disks support both RAID and HBA mode.


- The RAID mode is applicable to the disks that have been used to create a RAID volume.
- The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.
- In independent mode, each port can be set to the above three modes.

Steps

- Setting the Mode of All Ports

1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 3-56](#).

Figure 3-56 Configure Controller Settings Screen




2. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**. The **Configure Controller Port Mode** screen is displayed, see [Figure 3-57](#).


Figure 3-57 Configure Controller Port Mode Screen

3. Use the arrow keys to select **Set Controller Port Mode**, and then press **Enter**. The **Set Controller Port Mode** dialog box is displayed, see [Figure 3-58](#).

Figure 3-58 Set Controller Port Mode Dialog Box




4. Use the arrow keys to select the port mode to be set, and then press **Enter**, see [Figure 3-59](#).

Figure 3-59 Selecting a Port Mode

5. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully, see [Figure 3-60](#).

Figure 3-60 Successful Setting

6. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.
- Setting the Mode of a Single Port
 1. Perform [Step 1](#) through [Step 3](#) in [Setting the Mode of All Ports](#). The **Set Controller Port Mode** dialog box is displayed, as shown in [Figure 3-61](#).

Figure 3-61 Set Controller Port Mode Dialog Box

2. Use the arrow keys to select **Independent**, and then press **Enter** to set the port mode to **Independent**.
3. Set the mode of each port in the port list as required.
4. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully.

3.5.2 Locating a Disk


Abstract

After the indicator of a disk is lit, you can locate the disk so that you can easily replace or maintain it. You can locate a physical disk or multiple disks in a disk group.


Steps

- Locating a Single Physical Disk


1. On the controller management screen, use the arrow keys to select **Disk Utilities**, and then press **Enter**. The screen for the list of physical disks mounted on the **RAID** controller card is displayed, see [Figure 3-62](#).

Figure 3-62 Screen for the List of Disks Mounted on the RAID Controller Card

2. Use the arrow keys to select the disk to be located, and then press **Enter**. The screen for setting a disk is displayed, see [Figure 3-63](#).

Figure 3-63 Setting a Disk


3. Use the arrow keys to select **Identify Device**, and then press **Enter**. The **Identify Device** screen is displayed, see [Figure 3-64](#).

Figure 3-64 Identify Device Screen

4. Next to **Identification Duration (seconds)**, enter the time of the lighting delay (unit: seconds), select **Yes**, and press **Enter** for confirmation, see [Figure 3-65](#).


Figure 3-65 Lighting Delay

5. Use the arrow keys to select **Start**, and then press **Enter**. The status indicator of the hard disk is lit (as shown in [Figure 3-66](#)) and keeps solid blue.

Figure 3-66 Starting Locating a Disk

The indicator flashing duration is the configured lighting delay. After the lighting delay is reached, the default value 86400 s (24 hours) is restored, and the indicator goes out.

6. (Optional) To go out the disk indicator and end the locating, press **Esc** to return to the locating screen, use the arrow keys to select **Stop**, and press **Enter**, see [Figure 3-67](#).

Figure 3-67 Ending Disk Locating

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.
- Locating Multiple Disks in a Disk Group
 1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-68](#).


Figure 3-68 Array Configuration Screen



2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-69](#).

Figure 3-69 Managing Arrays Screen

3. Use the arrow keys to select the array in which the disks to be located are placed, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-70](#).

Figure 3-70 Managing the Selected Array


4. Use the arrow keys to select **Identify Device**, and then press **Enter**. The **Identify Device** screen is displayed, see [Figure 3-71](#).

Figure 3-71 Identify Device Screen

5. Next to **Identification Duration (seconds)**, enter the time of the lighting delay (unit: seconds), and then press **Enter** for confirmation, see [Figure 3-72](#).

Figure 3-72 Lighting Delay

6. Use the arrow keys to select **Start**, and then press **Enter**. The status indicators of the member disks of the array are lit up solid blue (as shown in [Figure 3-73](#)).

Figure 3-73 Starting Locating a Disk **Note**

The indicators of the hot spare disks belonging to the array are also lit and flash continuously at the same time. The indicator flashing duration is the configured lighting delay. After the lighting delay is reached, the default value 86400 s (24 hours) is restored, and the indicator goes out.

7. (Optional) To go out the disk indicator and end the locating, press **ESC** to return to the locating screen, use the arrow keys to select **Stop**, and press **Enter**, see [Figure 3-74](#).

Figure 3-74 Ending Disk Locating

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.3 Creating a Hot Spare Disk

Abstract

A hot spare disk improves the data security of a [RAID](#) array. For a description of the hot spare disk types supported by a SmartIOC 2100 [RAID](#) controller card, refer to [Table 3-10](#).

Table 3-10 Hot Spare Disk Types

Type	Description
Dedicated	<ul style="list-style-type: none"> • This type of hot spare disks is exclusive to the specified one or more disk groups of a RAID controller card. One or more hot spare disks can be created for each disk group. • When a disk in a disk group is faulty, a dedicated hot spare disk temporarily takes over the faulty disk.

Auto Replace	<ul style="list-style-type: none"> ● This type of hot spare disks provides the hot standby function for a disk group of a RAID controller card. One or more hot spare disks can be created for each disk group. ● When a disk in a disk group is faulty, a hot spare disk of this type automatically replaces the faulty disk.
---------------------	--

Prerequisite

There are sufficient idle disks on the server.

Context


When creating a hot spare disk, pay attention to the following points:

- Multiple hot spare disks can be created for a disk group, but only one type of hot spare disk can be set at a time. That is, either **Dedicated** or **Auto Replace** is specified.
- An idle disk can be set as a hot spare disk. The disk that has been used to create a RAID volume cannot be set as a hot spare disk.
- The hot spare disk must be of the same type as that of any member disk in the corresponding disk group. That is, all of them are **SATA** disks or **SAS** disks, and the hot spare disk's capacity must not be less than the maximum capacity of the member disks.
- Disk groups at all levels except RAID 0 support hot spare disks.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-75](#).


Figure 3-75 Array Configuration Screen




2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-76](#).

Figure 3-76 Managing Arrays Screen

3. Use the arrow keys to select the array for which you need to create the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-77](#).

Figure 3-77 Managing the Selected Array

4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 3-78](#).

Figure 3-78 Manage Spare Drives Screen

5. In accordance with your actual conditions, use the arrow keys to select the type of the hot spare disk to be created, and then press **Enter**. The screen for selecting a hot spare disk is displayed, see [Figure 3-79](#).

Figure 3-79 Selecting a Hot Spare Disk

6. Use the arrow keys to select the disk to be set as a hot spare disk, press **Enter**, and set the status of the disk to **Enabled**, see [Figure 3-80](#).

Figure 3-80 Setting Disk Status

7. Use the arrow keys to select **Assign Dedicated Spare**, and then press **Enter**. The hot spare disk is successfully created, see [Figure 3-81](#).

Figure 3-81 Hot Spare Disk Created Successfully

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.4 Changing a Hot Spare Disk

Abstract

A SmartIOC 2100 **RAID** controller card supports modifying the type of a hot spare disk, namely, allowing type change between **Dedicated** and **Auto Replace**.

Only one type of hot spare disk can be set at a time. That is, **Dedicated** and **Auto Replace** cannot be specified at the same time. This procedure uses changing a hot spare disk of the Dedicated type to that of the Auto Replace type as an example to describe how to perform a type change.



A hot spare disk of the **Auto Replace** type can be changed to that of the **Dedicated** type by referring to this procedure.


Prerequisite

A hot spare disk is already set to the **Dedicated** type. For details, refer to “[3.5.3 Creating a Hot Spare Disk](#)”.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-82](#).

Figure 3-82 Array Configuration Screen




2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-83](#).

Figure 3-83 Managing Arrays Screen



3. Use the arrow keys to select the array for which you need to modify the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-84](#).

Figure 3-84 Managing the Selected Array

4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 3-85](#).

Figure 3-85 Manage Spare Drives Screen

5. Use the arrow keys to select **Change Spare type to Auto Replace**, and then press **Enter**.

The **Change Spare type to Auto Replace** screen is displayed, see [Figure 3-86](#).

Figure 3-86 Change Spare Type to Auto Replace Screen

6. Select **Submit Changes**, and then press **Enter**. The type of hot spare disk is changed successfully, see [Figure 3-87](#).

Figure 3-87 Hot Spare Disk Type Changed Successfully

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.5 Deleting a Hot Spare Disk

Abstract


When the number of disks of a server cannot meet the requirements, you can delete an existing hot spare disk and restore it to a common disk.

Prerequisite

A hot spare disk is already created. For details, refer to "[3.5.3 Creating a Hot Spare Disk](#)".

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-88](#).


Figure 3-88 Array Configuration Screen

2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-89](#).

Figure 3-89 Managing Arrays Screen



3. Use the arrow keys to select the array for which you need to delete the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-90](#).

Figure 3-90 Managing the Selected Array

4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 3-91](#).

Figure 3-91 Manage Spare Drives Screen

5. Use the arrow keys to select **Delete Spare Drives**, and then press **Enter**. The **Delete Spare Drives** screen is displayed, see [Figure 3-92](#).

Figure 3-92 Delete Spare Drives Screen

6. Use the arrow keys to select the hot spare disk to be deleted, press **Enter**, and then set the status of the disk to **Enabled**, see [Figure 3-93](#).

Figure 3-93 Setting Disk Status



7. Use the arrow keys to select **Delete Spare Drive**, and then press **Enter**. The hot spare disk is successfully deleted, see [Figure 3-94](#).

Figure 3-94 Hot Spare Disk Deleted Successfully

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.6 Configuring the Performance or Power Mode

Abstract

This procedure describes how to configure the power mode for a SmartIOC 2100 [RAID](#) controller card. For a description of the power modes supported by the SmartIOC 2100 [RAID](#) controller card, refer to [Table 3-11](#).


Table 3-11 Power Mode Descriptions

Power Mode	Description
Minimum Power	In this mode, the static settings of the power are adjusted to the possible lowest value, and the power is dynamically reduced based on the working load.
Maximum Performance	In this mode, the static settings of the power are adjusted to the possible highest value, and the power is not dynamically reduced based on the working load.


Steps

1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 3-95](#).

Figure 3-95 Configure Controller Settings Screen




2. Use the arrow keys to select **Manage Power Settings**, and then press **Enter**. The **Manage Power Settings** screen is displayed, see [Figure 3-96](#).

Figure 3-96 Manage Power Settings Screen

3. Use the arrow keys to select **Power Mode**, and then press **Enter**. The **Power Mode** menu is displayed, see [Figure 3-97](#).

Figure 3-97 Power Mode Menu



4. In accordance with your actual conditions, use the arrow keys to select the power mode to be applied, and then press **Enter** for confirmation, see [Figure 3-98](#).

Figure 3-98 Selecting a Power Mode


5. (Optional) Determine whether to enable **Survival Mode** as required.



By default, **Survival Mode** is enabled, indicating that when the working temperature of the power supply exceeds the threshold, the RAID controller card is allowed to switch to the energy saving mode, but it may cause performance deterioration.

a. Use the arrow keys to select **Survival Mode**, and then press **Enter**. The **Survival Mode** menu is displayed, see [Figure 3-99](#).

Figure 3-99 Survival Mode Menu



b. Use the arrow keys to select **Disabled**, and then press **Enter**. The **Survival Mode** is disabled, see [Figure 3-100](#).

Figure 3-100 Disabling Survival Mode

6. Use the arrow keys to select **Submit Changes**, and press **Enter**. The power mode is set successfully, see [Figure 3-101](#).

Figure 3-101 Power Mode Configured Successfully

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.7 Deleting a RAID volume

Abstract

When a server no longer needs a **RAID** volume, you can delete the RAID volume to release the disk space.



Notice

- The data that is lost during deletion of the RAID volume cannot be restored. Therefore, you must make sure that you have backed up important data before deleting the volume.
- If the RAID logical volume to be deleted is the only logical volume on the current array, the array is also deleted after the RAID logical volume is deleted.

Prerequisite

A RAID volume is created successfully. For details, refer to “[3.3.2 Creating a RAID Volume](#)”

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-102](#).

[Figure 3-102 Array Configuration Screen](#)




2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-103](#).

Figure 3-103 Managing Arrays Screen




3. Use the arrow keys to select the array for which you need to delete a logical volume, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-104](#).

Figure 3-104 Managing the Selected Array


4. Use the arrow keys to select **List Logical Drives**, and then press **Enter**. The **List Logical Drives** screen is displayed, see [Figure 3-105](#).

Figure 3-105 List Logical Drives Screen

5. Use the arrow keys to select the logical volume to be deleted, and then press **Enter**. The screen for managing the selected logical volume is displayed, see [Figure 3-106](#).

Figure 3-106 Managing the Selected Logical Volume

6. (Optional) To view the details of the logical volume, use the arrow keys to select **Logical Drive Details**, and then press **Enter**, see [Figure 3-107](#).

Figure 3-107 Viewing Logical Volume Details Screen

7. On the logical volume management screen, use the arrow keys to select **Delete Logical Drive**, and then press **Enter**. The confirmation screen for RAID volume deletion is displayed, see [Figure 3-108](#).

Figure 3-108 Confirmation Screen for RAID Volume Deletion

8. Select **Submit Changes**, and then press **Enter**. The logical volume is deleted successfully, see [Figure 3-109](#).

Figure 3-109 Logical Volume Deleted Successfully

9. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.8 Deleting a Disk Group

Abstract

When a server no longer needs a disk group (array), you can delete it to release the disk space.



Notice

- When an array is deleted, the **RAID** logical volume built on it is also deleted, and the data lost during the deletion cannot be restored. Therefore, it is required to make sure that you have backed up important data before the deletion.
- If the array to be deleted is the only array of the RAID controller card, the configurations related to the RAID controller card are also cleared, and the default configurations are restored.

Prerequisite

A RAID volume is created successfully to form a disk group. For details, refer to “[3.3.2 Creating a RAID Volume](#)”.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 3-110](#).

[Figure 3-110 Array Configuration Screen](#)




2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 3-111](#).


Figure 3-111 Managing Arrays Screen



3. Use the arrow keys to select the array to be deleted, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 3-112](#).

Figure 3-112 Managing the Selected Array

4. Use the arrow keys to select **Delete Array**, and then press **Enter**. The **Delete Array** screen is displayed, see [Figure 3-113](#).

Figure 3-113 Delete Array Screen

5. Use the arrow keys to select **Submit Changes**, and press **Enter**. The array is deleted successfully, see [Figure 3-114](#).

Figure 3-114 Array Deleted Successfully

6. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.9 Clearing RAID Configuration Information

Abstract

This procedure describes how to clear all configuration information that is already created on a SmartIOC 2100 **RAID** controller card.



Notice

The data that is lost during clearing of the configuration information on the RAID controller card cannot be restored. Therefore, it is required to make sure that you have backed up important data before the clearing operation.

Prerequisite

A RAID volume is created successfully and it has the corresponding RAID configuration information. For details, refer to “[3.3.2 Creating a RAID Volume](#)”.


Steps

1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 3-115](#).

Figure 3-115 Configure Controller Settings Screen



2. Use the arrow keys to select **Clear Configuration**, and then press **Enter**. The **Clear Configuration** screen is displayed, see [Figure 3-116](#).

Figure 3-116 Clear Configuration Screen

3. Use the arrow keys to select **Delete All Array Configuration**, and then press **Enter**. The **Delete All Array Configuration** screen is displayed, see [Figure 3-117](#).

Figure 3-117 Delete All Array Configuration Screen



4. Use the arrow keys to select **Submit Changes**, and press **Enter**. The configuration information is cleared successfully, see [Figure 3-118](#).

Figure 3-118 Configuration Cleared Successfully

5. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

3.5.10 Configuring a Pass-Through Disk

Abstract

When the mode of the ports of a SmartIOC 2100 RAID controller card is set to **HBA**, the hard disks connected to these ports can be configured as pass-through disks.

Context

The port modes are described as follows:


- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.
- In mixed mode, the connected disks support both RAID and HBA mode.
 - The RAID mode is applicable to the disks that have been used to create a RAID volume.

- The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.
- In independent mode, each port is allowed to use any of the above three modes.


Steps

1. On the controller management screen, use the arrow keys to select **Controller Information**, and then press **Enter**. The **Controller Information** screen is displayed. The value of **Controller Mode** is **Mixed**, see [Figure 3-119](#).

Figure 3-119 Controller Information Screen



2. Press **Esc** to return to the controller management screen. Use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 3-120](#).

Figure 3-120 Configure Controller Settings Screen

3. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**. The **Configure Controller Port Mode** screen is displayed, see [Figure 3-121](#).

Figure 3-121 Configure Controller Port Mode Screen

4. Use the arrow keys to select **Set Controller Port Mode**, and then press **Enter**. The **Set Controller Port Mode** dialog box is displayed, see [Figure 3-122](#).

Figure 3-122 Set Controller Port Mode Dialog Box


5. Use the arrow keys to select **HBA**, and then press **Enter**. The mode of all ports is set to **HBA**, see [Figure 3-123](#).

Figure 3-123 Setting the Port Mode to HBA


6. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully, see [Figure 3-124](#).

Figure 3-124 Port Mode Set Successfully

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen, see [Figure 3-125](#).

Figure 3-125 Controller Management Screen

8. Use the arrow keys to select **Controller Details**, and then press **Enter**. On the displayed **Controller Information** screen, view the port mode after the modification, see [Figure 3-126](#). The value of **Controller Mode** is **HBA**.

Figure 3-126 Controller Information Screen

3.6 Typical Scenarios for Replacing a Disk (Legacy Mode)

For a description of the common scenarios for replacing disks in a RAID volume on a SmartIOC 2100 RAID card in legacy mode, refer to [Table 3-12](#).

Table 3-12 Common Scenarios for Replacing a Disk in a RAID Volume on a SmartIOC 2100 RAID Controller Card

Scenario	Description
Scenario 1	A newly inserted disk is converted into a RAID member disk. For details, refer to " 3.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk ".
Scenario 2	After a faulty SmartIOC 2100 RAID card is replaced, all the member disks in the RAID 1 array managed by the original faulty RAID card are moved to a new RAID card. For details, refer to " 3.6.2 Moving All Member Disks of a RAID 1 Volume ".

3.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk

Abstract

A newly inserted disk needs to be converted into a RAID member disk in the following two cases:

- The newly inserted disk is a foreign disk.
- The disk in a slot is removed and inserted back.

Inserting a Foreign Disk as a New Disk

When a disk in a RAID volume created on a server is faulty and needs replacement, remove the faulty disk from the disk slot on the server, and insert the prepared disk into the disk slot of the faulty disk.

After the disk is replaced, the configuration utility of the RAID controller card automatically synchronizes data on the newly inserted disk in the RAID volume.



Note

Data is automatically synchronized to the newly inserted disk no matter whether it carries RAID information or not.

Installing a Disk in the Original Slot After Removing It from the Slot

After a disk on a server is used to create a RAID volume, if the disk is removed from its slot and then inserted back, the RAID controller card configuration utility automatically rebuild the disk.



Note

The RAID 0 volume does not support the above functions.

3.6.2 Moving All Member Disks of a RAID 1 Volume

Abstract

If a SmartIOC 2100 RAID controller card on a server fails and needs to be replaced, all the member disks in the RAID 1 volume on the faulty RAID controller card need to be moved to a new SmartIOC 2100 RAID controller card.



Notice

It is risky to move the member disks of the RAID volume, and therefore it is recommended that you contact NETAŞ technical support for help.

Steps

1. Shut down the server, and replace the faulty SmartIOC 2100 RAID controller card with a new one.

2. Connect all member disks of the RAID 1 volume be moved to the new SmartIOC 2100 RAID controller card.
3. Power on the server again and start the server system.
4. Start the [BIOS](#) configuration utility. For details, refer to “[3.2.1 Starting the Configuration Utility](#)”.
5. Query RAID volume information. For details, refer to “[3.4.1 Querying RAID Volume Information](#)”.
6. Contact NETAŞ technical support to move member disks.

3.7 Typical Scenarios for Replacing a Disk (UEFI Mode)

For a description of the common scenarios for replacing a disk in a RAID volume on a SmartIOC 2100 [RAID](#) card in [UEFI](#) mode, refer to [Table 3-13](#).

Table 3-13 Common Scenarios for Replacing a Disk in a RAID Volume on a SmartIOC 2100 RAID Controller Card

Scenario	Description
Scenario 1	When a RAID 0 member disk is faulty, the RAID controller card is reconfigured. For details, refer to “ 3.7.1 A RAID 0 Member Disk Fails ”.
Scenario 2	When a member disk of a logical volume with no hot spare disk configured is faulty, the faulty disk is replaced. For details, refer to “ 3.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails ”.
Scenario 3	When a member disk of a logical volume with a hot spare disk configured is faulty, the faulty disk is replaced. For details, refer to “ 3.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails ”.

3.7.1 A RAID 0 Member Disk Fails

[RAID](#) 0 does not support data redundancy or backup. As a result, data cannot be restored after a fault occurs in the RAID 0 logical volume. It is necessary to install a new disk and reconfigure the RAID array.

3.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails

Abstract

If a fault occurs in a member disk of a redundant logical volume (with no hot spare disk configured) on a SmartIOC 2100 [RAID](#) controller card, the SmartIOC 2100 RAID controller card

can automatically restore the data after the faulty disk is replaced with a new disk. During the process, the member disk status may be **OK**, but the logical disk status may be **Failed**. In this case, you need to restore the logical disk status.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The screen for configuring an array is displayed.
2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The screen for managing arrays is displayed.
3. Use the arrow keys to select the array for which you need to manage the logical volume, and then press **Enter**. The screen for managing the selected array is displayed.
4. Use the arrow keys to select **List Logical Drives**, and then press **Enter**. The screen for managing logical volumes is displayed.
5. Use the arrow keys to select the logical volume to be corrected, and then press **Enter**. The screen for managing the selected logical volume is displayed.
6. Use the arrow keys to select **Re-Enable Logical Drive**, and then press **Enter**. The screen for restoring logical volume status is displayed.
7. Press **Enter**. The status of the logical disk is restored.

Verification

On the logical volume management screen, use arrow keys to select **Logical Drive Details**, and then press **Enter**. The logical volume details are displayed. Verify that the logical volume status is **Ok**.

3.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails

When a fault occurs in a member disk of a redundant logical volume (with a hot spare disk configured) on a SmartIOC 2100 [RAID](#) controller card, the RAID controller card automatically replaces the faulty disk with the hot spare disk and restores the data.

- When the hot spare disk is of the **Dedicated** type, the RAID controller card temporarily replaces the faulty disk with the hot spare disk and automatically restores the data. After the faulty disk is replaced with a new disk, the hot spare disk is restored to Hot Spare status.
- When the hot spare disk is of the **Auto Replace** type, the RAID controller card immediately replaces the faulty disk with the hot spare disk and automatically restores the data. After the new disk is inserted, the new disk becomes a hot spare disk.

Chapter 4

NETAŞ SmartROC 3100

RAID Controller Card

Table of Contents

Capability Features.....	142
Initial Configuration (Legacy Mode).....	143
Initial Configuration (UEFI Mode).....	152
Common Configurations (Legacy Mode).....	165
Common Configurations (UEFI Mode).....	189
Typical Scenarios for Replacing a Disk (Legacy Mode).....	273
Typical Scenarios for Replacing a Disk (UEFI Mode).....	275

A **NETAŞ** SmartROC 3100 **RAID** controller card is integrated with the **BIOS** configuration utility. By using the program, you can configure the disks that are supported by the **NETAŞ** SmartROC 3100 RAID controller card to a RAID volume of a specific level.

A **NETAŞ** SmartROC 3100 **RAID** controller card supports the caching function, which can improve read/write performance.



Note

The operation screens of the BIOS configuration utility displayed in this chapter are for reference only, and may not be the same as the actual ones.

4.1 Capability Features

For a description of the capabilities of a **NETAŞ** SmartROC 3100 **RAID** controller card, refer to **Table 4-1**.


Table 4-1 Descriptions of the Capabilities of a **NETAŞ SmartROC 3100 **RAID** Controller Card**

Capability Item	Capability Parameter
Product form	Mezz card

Controller chip	PMC PM8236
Capability Item	Capability Parameter
Host interface	PCIe 3.0x8
SAS interface	12 Gb SAS
Number of ports	16+2
Drive interface	SAS and SATA
Drive type	HDD and SSD
Whether drives are hot swappable	Supported
Maximum number of RAID groups	64
Number of drives	238
RAID level	RAID 0, RAID 1, RAID 10, RAID 5, RAID 50, RAID 6, RAID 60
JBOD mode	Supported
Cache	2 GB/4 GB
Cache protection	Super capacitor
Out-of-band management	Supported
Consistency check/verification and fix	Supported
Online capacity expansion	Supported
Online RAID level migration	Supported
Automatic rebuild	Supported
Manufacturer tool support	arcconf

4.2 Initial Configuration (Legacy Mode)

Figure 4-1 shows the initial configuration flow of a NETAŞ SmartROC 3100 RAID controller card.

Figure 4-1 Initial Configuration Flow of a NETAŞ SmartROC 3100 RAID Controller Card

4.2.1 Starting the Configuration Utility

Abstract

This procedure describes how to start the **BIOS** configuration utility of a NETAŞ SmartROC 3100 **RAID** controller card to log in to the management screen and complete the subsequent initial and common configurations.

Prerequisite

The boot mode is already set to **Legacy** in **BIOS**. For details, refer to "[5.2.1 Setting the Boot Mode to Legacy](#)".

Steps


1. Start the server system.
2. During the **POST** process, press **Ctrl+A** to start the **BIOS** configuration utility of the NETAŞ SmartROC 3100 RAID controller card. The screen as shown in [Figure 4-2](#) is displayed.

Figure 4-2 BIOS Configuration Utility Screen



3. In the **Options** area, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Configuration Menu** screen is displayed, see [Figure 4-3](#).

Figure 4-3 Configuration Menu Screen



4.2.2 Creating a RAID Volume

Abstract

You can create **RAID** volumes at different levels as required.

The procedures for creating RAID volumes at different levels are similar. This procedure uses a RAID 0 volume in legacy mode as an example.

Prerequisite

Sufficient [SATA](#) and [SAS](#) disks are installed on the server.

Context


For a description of the number of disks required to create a RAID volume, refer to [Table 4-2](#).

Table 4-2 Number of Disks Required for Creating a RAID Volume


RAID Level	Description
RAID 0	RAID 0 requires at least one disks.
RAID1	RAID 1 requires at least two disks. Disks with different capacities can be used in a RAID 1 volume, but the logical capacity of each member disk depends on the space of the disk with the smallest capacity.
RAID 5	RAID 5 requires at least three disks.
RAID 6	RAID 6 requires at least four disks.
RAID 10	RAID 10 requires at least four disks. A RAID 10 volume consists of at least two RAID 1 volumes. For example, if there are four disks to be used in RAID 10 mode, you need to add them to two drive groups, each of which is mounted with two disks in RAID 1 mode.
RAID 50	RAID 50 requires at least six disks. A RAID 50 volume consists of at least two RAID 5 volumes. For example, if there are six disks to be used in RAID 50 mode, you need to add them to two drive groups, each of which is mounted with three disks in RAID 5 mode.
RAID 60	RAID 60 requires at least eight disks. A RAID 60 volume consists of at least two RAID 6 volumes. For example, if there are eight disks to be used in RAID 60 mode, you need to add them to two drive groups, each of which is mounted with four disks in RAID 6 mode.

Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Create Array**, and then press **Enter**. On the displayed **Select drives to create Array** screen, all the disks that can be used to create a RAID volume are displayed, see [Figure 4-4](#).


Figure 4-4 Select Drives to Create Array Screen

2. Use the arrow keys to select the disks to be used to create the RAID volume, and then press **Insert** to add these disks to the **Selected Drives** list, see [Figure 4-5](#).

Figure 4-5 Selected Drives List

- The disks for creating a RAID volume must be of the same type. It is forbidden to select disks with interface types such as **SATA** and **SAS** at the same time.
- Press the **Delete** key to delete the selected disk from the **Selected Drives** list.

3. Press **Enter**. The **Create Logical Drive** screen is displayed, see [Figure 4-6](#).

Figure 4-6 Create Logical Drive Screen


4. Use **Tab/Tab+Shift** to select the parameters that you want to modify. In the displayed operation box, use the arrow keys to select the related parameters, and then press **Enter** for confirmation. For a description of the parameters on the **Create Logical Drive** screen, refer to [Table 4-3](#).

Table 4-3 Descriptions of the Parameters on the Create Logical Drive Screen


Parameter	Description
RAID Level	Sets a RAID level, for example, RAID 0(Stripe) .
Logical Drive Name	Sets the RAID name, for example, "0".
Strip/Full Stripe Size	The stripe size should be equal to the size of average disk IO requests generated by server applications. In the optimum status, only one IO operation is executed for each IO request. The recommended stripe size configurations are as follows: <ul style="list-style-type: none"> For a Web server, 8 KB is recommended. For a groupware server (such as an email server), 16 KB is recommended. For a database server, 16 KB or 32 KB is recommended. For a file server, 32 KB or 64 KB is recommended For a video file server, 64 KB, 128 KB, or 256 KB is recommended.
Parity Group Count	Configures logical-device parity groups in accordance with the number of physical devices in the array. It is not applicable to all RAID levels.
Parameter	Description

Build Method	<p>Sets the RAID initialization method, which is used to determine how the logical devices prepare for read and write, and how long the initialization takes.</p> <ul style="list-style-type: none"> ● default: When the logical devices can be accessed by the operating system, parity blocks are initialized at the back end. A lower RAID level can achieve faster parity initialization. ● RPI: The data and parity blocks at the front end are overwritten. Before the parity initialization procedure is completed, logical devices remain invisible and unavailable to the operating system. All parity groups are initialized in parallel, but the initialization of a single parity group (RAID 5) is faster. The RAID level does not affect the performance during the RAID initialization. ● Not Applicable: unavailable. <p>Keep the default configuration unless otherwise specified.</p>
Size	<p>Displays the storage size of the disk array in accordance with the total storage space of the disks added to the disk array.</p> <p>By default, the RAID created uses all the available disk space.</p>
Acceleration Method	<p>Sets the caching mode for the RAID volume.</p> <ul style="list-style-type: none"> ● IO Bypass: This option is valid only when the RAID logical volume is formed by SSDs. ● Controller Cache: enables controller cache optimization. The read cache and write cache are used at the same time. ● None: disables the controller cache. Neither IO Bypass nor Controller Cache is used. <p>Keep the default configuration unless otherwise specified.</p>

5. Use **Tab** to select **Done**, and then press **Enter** to create the RAID volume, see [Figure 4-7](#).

Figure 4-7 Creating a RAID Volume

6. The RAID volume is created successfully, see [Figure 4-8](#). Press any key to return to the **Configuration Menu** screen.

Figure 4-8 RAID Volume Created Successfully

4.2.3 Configuring a Boot Device

Abstract

After a **RAID** volume is created, if you need to install an operating system on the RAID volume, and there are multiple RAID volumes on the RAID controller card, you must set the RAID volume as a boot device.


Prerequisite

A RAID volume is created successfully. For details, refer to “[4.2.2 Creating a RAID Volume](#)”.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** page is displayed, see [Figure 4-9](#).


Figure 4-9 List of Arrays Screen



2. Use the arrow keys to select the array where the RAID volume to be set as a boot device is located, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 4-10](#).


Figure 4-10 List of Logical Drives Screen

3. Select the RAID volume to be booted first, and then press **Ctrl+P** to configure it as the first boot device, see [Figure 4-11](#).

Figure 4-11 Configuring a Boot Device

4.3 Initial Configuration (UEFI Mode)

[Figure 4-12](#) shows the initial configuration flow of a NETAŞ SmartROC 3100 RAID controller card.

Figure 4-12 Initial Configuration Flow of a NETAŞ SmartROC 3100 RAID Controller Card**Note**

- The SmartROC 3100 RAID controller card is in [UEFI](#) mode, and it currently does not support the boot disk settings.
- The SmartROC 3100 RAID controller card does not support the co-existence of configurations in both UEFI and legacy modes. If the mode is switched from UEFI to legacy, the configuration in UEFI mode must be cleared. Otherwise, the normal operation of the RAID controller card is affected.

4.3.1 Starting the Configuration Utility

Abstract


This procedure describes how to start the [BIOS](#) configuration utility of a NETAŞ SmartROC 3100 [RAID](#) controller card to log in to the management screen and complete the subsequent initial and common configurations.

Prerequisite


The boot mode is already set to [UEFI](#) in [BIOS](#). For details, refer to "[5.2.2 Setting the Boot Mode to UEFI](#)".

Steps

1. Start the server system.
2. During the [POST](#) process, press **F2/DEL**. The **Aptio Setup** screen is displayed, see [Figure 4-13](#).

Figure 4-13 Aptio Setup Screen

3. Use the arrow keys to select **Advanced**, and then press **Enter**. The **Advanced** screen is displayed, see [Figure 4-14](#).

Figure 4-14 Advanced Screen

4. Use the arrow keys to select **NETAŞ SmartROC3100 RM242-18i 4G**, and press **Enter**. The controller management screen is displayed, see [Figure 4-15](#).

Figure 4-15 Controller Management Screen

For a description of the functions of the menus on the controller management screen, refer to [Table 4-4](#).

Table 4-4 Functions of Menus on the Controller Management Screen

Menu	Function Description
Controller Information	Displays the basic information, firmware, current temperature, and port configuration of the controller.
Configure Controller Settings	Provides advanced configuration options for the controller.
Array Configuration	Creates an array or RAID.
Disk Utilities	Displays the list of disk devices mounted under the controller as well as the basic disk information. It allows you to turn on the disk location indicator, erase disk data and upgrade the firmware.
Set Bootable Device(s) for Legacy Boot Mode	Configures, or clears the primary and secondary boot disks.
Administration	Allows the controller administrator to perform operations, such as upgrading the firmware and restoring factory defaults.

4.3.2 Creating a RAID Volume

Abstract

You can create **RAID** volumes at different levels as required.

The operations for creating RAID volumes at different levels are similar. This procedure uses creating a RAID 1 volume in **UEFI** mode as an example.

Prerequisite

- Sufficient **SATA** and **SAS** disks are installed on the server.
- The port mode for the disks to be connected is already set. For details, refer to "[4.5.1 Setting the Mode of a Port](#)".

Context

For a description of the number of disks required to create a RAID volume, refer to [Table 4-5](#).

Table 4-5 Number of Disks Required for Creating a RAID Volume

RAID Level	Description
RAID 0	RAID 0 requires at least one disks.
RAID 1	RAID 1 requires at least two disks. Disks with different capacities can be used in a RAID 1 volume, but the logical capacity of each member disk depends on the space of the disk with the smallest capacity.
RAID 5	RAID 5 requires at least three disks.
RAID 6	RAID 6 requires at least four disks.
RAID 1+0	RAID 1+0 requires at least four disks. A RAID 1+0 volume consists of at least two RAID 1 volumes. For example, if there are four hard disks to be stored in the RAID 1+0 mode, you need to add them to two "Drive Group," and each "Drive Group" mounts two hard disks. The storage mode is RAID 1.
RAID 50	RAID 50 requires at least six disks. A RAID 50 volume consists of at least two RAID 5 volumes. For example, if six hard disks need to be stored in the RAID 50 mode, it is necessary to add six hard disks to two "Drive Group," each of which is mounted with three hard disks, and the storage mode is RAID 5.

RAID 60	<p>RAID 60 requires at least eight disks.</p> <p>A RAID 60 volume consists of at least two RAID 6 volumes. For example, if there are eight disks to be used in RAID 60 mode, you need to add them to two drive groups, each of which is mounted with four disks in RAID 6 mode.</p>
---------	---


Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-16](#).


Figure 4-16 Array Configuration Screen



2. Use the arrow keys to select **Create Array**, and then press **Enter**. In the displayed disk list, all the disks that can be used to create a RAID volume are displayed, see [Figure 4-17](#).

Figure 4-17 Viewing the Disk List

3. Select the disk to be added to the array, and then press **Enter** to set the disk port to **Enabled** status, see [Figure 4-18](#).

Figure 4-18 Confirming the Configuration**Note**


The disks for creating a RAID volume must be of the same type. It is forbidden to select disks with interface types such as **SATA** and **SAS** at the same time.

4. Use the arrow keys to select **Proceed to Next Form**, and then press **Enter**. The screen for creating RAID is displayed, see [Figure 4-19](#).


Figure 4-19 Creating RAID



5. Use the arrow keys to select **RAID Level**, and then press **Enter**. From the displayed shortcut menu, select the desired RAID level, see [Figure 4-20](#).

Figure 4-20 Selecting a RAID Level

6. Use the arrow keys to select **Proceed to Next Form**, and press **Enter**. The screen for setting RAID logical volumes is displayed, see [Figure 4-21](#).

Figure 4-21 Setting RAID Logical Volumes

7. Use the arrow keys to select the parameters that you want to modify. In the displayed operation boxes, configure the related parameters. For a description of the parameters for setting a logical volume, refer to [Table 4-6](#).

Table 4-6 Parameter Descriptions for Logical Volume Configuration

Parameter	Description
Logical Drive Label	Sets the name of the RAID logical volume, for example, "Logical Drive 1".
Strip Size/Full Strip Size	<ul style="list-style-type: none"> Strip Size indicates the size of the current stripe. The stripe size should be equal to the size of average disk IO requests generated by server applications. In the optimum status, only one IO operation is executed for each IO request. The size can be 16 KiB, 32 KiB, 64 KiB, 128KiB, 512 KiB, or 1024 KiB. The default value is 256 KiB. The recommended stripe size configurations are as follows: <ul style="list-style-type: none"> For a Web server, 8 KiB is recommended. For a groupware server (such as an email server), 16 KiB is recommended. For a database server, 16 KiB or 32 KiB is recommended. For a file server, 32 KiB or 64 KiB is recommended. For a video file server, 64 KiB, 128 KiB, or 256 KiB is recommended.

Parameter	Description
	<ul style="list-style-type: none"> ● Full Strip Size indicates the total size of all stripes. When you set Strip Size, the system automatically calculates Full Stripe Size.
Size	<p>Displays the storage size of the RAID volume in accordance with the total storage space of the disks added to the RAID volume.</p> <p>By default, all available space is used to create a RAID logical volume. To create multiple RAID logical volumes, you can define the size of the volumes.</p>
Unit Size	Select the unit (MiB/GiB/TiB) of the logical drive.
Acceleration Method	<p>Sets the caching mode for the RAID volume.</p> <ul style="list-style-type: none"> ● IO Bypass: This option is valid only when the RAID logical volume is formed by SSDs. ● Controller Cache: enables controller cache optimization. The read cache and write cache are used at the same time. ● None: disables the controller cache. Neither IO Bypass nor Controller Cache is used. <p>Keep the default configuration unless otherwise specified.</p>

8. Use the arrow keys to select **Submit Changes**, and press **Enter**. The RAID volume is created successfully, see [Figure 4-22](#).

Figure 4-22 RAID Volume Created Successfully

9. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.4 Common Configurations (Legacy Mode)

By using the **BIOS** configuration utility, you can configure and maintain a created **RAID** volume. For a description of the common operations on a SmartROC 3100 RAID controller card in legacy mode, refer to [Table 4-7](#).

Table 4-7 Common Operations on a SmartROC 3100 RAID Controller Card

Common Operation	Description
Querying RAID volume information	Refer to " 4.4.1 Querying RAID Volume Information ".
Creating a hot spare disk	Refer to " 4.4.2 Creating a Hot Spare Disk ".
Deleting a RAID volume	Refer to " 4.4.3 Deleting a RAID Volume ".
Deleting a hot spare disk	Refer to " 4.4.4 Deleting a Hot Spare Disk ".

Locating a disk	Refer to " 4.4.5 Locating a Disk ".
Common Operation	Description
Configuring a pass-through disk	Refer to " 4.4.6 Configuring a Pass-Through Disk ".
Enabling the caching function	Refer to " 4.4.7 Enabling the Caching Function ".

4.4.1 Querying RAID Volume Information

Abstract

This procedure describes how to query the **RAID** information created on a SmartROC 3100 RAID controller card, such as the RAID volume status and member disk status.


Prerequisite

A RAID volume is created successfully. For details, refer to "[4.2.2 Creating a RAID Volume](#)".


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 4-23](#).


Figure 4-23 List of Arrays Screen




2. Select the RAID volume whose properties you want to view, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 4-24](#).

Figure 4-24 List of Logical Drives Screen

3. Press **Enter**. In the displayed **Logical Drive Details** dialog box, view the property information about the RAID volume, see [Figure 4-25](#).

Figure 4-25 Logical Drive Details Dialog Box

4. (Optional) To view the member disk information, press **Ctrl+D**. The **Array Member Drives** dialog box is displayed, see [Figure 4-26](#).

Figure 4-26 Array Member Drives Dialog Box

4.4.2 Creating a Hot Spare Disk

Abstract

A hot spare disk improves the data security of a [RAID](#) array. For a description of the hot spare disk types supported by a SmartROC 3100 [RAID](#) controller card, refer to [Table 4-8. Table 4-8 Hot Spare Disk Types](#)

Type	Description
Dedicated	<ul style="list-style-type: none"> This type of hot spare disks is exclusive to the specified one or more disk groups of a RAID controller card. One or more hot spare disks can be created for each disk group. When a disk in a disk group is faulty, a dedicated hot spare disk temporarily takes over the faulty disk.
Auto Replace	<ul style="list-style-type: none"> This type of hot spare disks provides the hot standby function for a disk group of a RAID controller card. One or more hot spare disks can be created for each disk group. When a disk in a disk group is faulty, a hot spare disk of this type automatically replaces the faulty disk.

Prerequisite

There are sufficient idle disks on the server.

Context


When creating a hot spare disk, pay attention to the following points:

- Multiple hot spare disks can be created for a disk group, but only one type of hot spare disk can be set at a time. That is, either **Dedicated** or **Auto Replace** is specified.
- An idle disk can be set as a hot spare disk. The disk that has been used to create a RAID volume cannot be set as a hot spare disk.
- The hot spare disk must be of the same type as that of any member disk in the corresponding disk group. That is, all of them are **SATA** disks or **SAS** disks, and the hot spare disk's capacity must not be less than the maximum capacity of the member disks.
- Disk groups at all levels except RAID 0 support hot spare disks.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 4-27](#).


Figure 4-27 List of Arrays Screen



2. Use the arrow keys to select the RAID volume for which you want to configure a hot spare disk, and press **Ctrl+S**. The **Select Hotspare Drives** screen is displayed, see [Figure 4-28](#).


Figure 4-28 Select Hotspare Drives Screen

3. Use the arrow keys to select the idle disk to be set as a hot spare disk, and then press **Insert** to add the disk to the **Selected Drives** list, see [Figure 4-29](#).


Figure 4-29 Selected Drives Screen

Press the **Delete** key to delete the selected disk from the **Selected Drives** list.


4. Press **Enter**. A confirmation dialog box is displayed, see [Figure 4-30](#).

Figure 4-30 Confirmation Dialog Box


5. At the cursor in the confirmation dialog box, enter **Y**. The **Select Spare Type** screen is displayed, see [Figure 4-31](#).

Figure 4-31 Select Spare Type Screen

6. Use the arrow keys to select the type of hot spare disk to be created, and then press **Enter** for confirmation, see [Figure 4-32](#).

Figure 4-32 Select Spare Type Screen

7. Use **Tab** to select **Done**, and then press **Enter** to create the hot spare disk, see [Figure 4-33](#).

Figure 4-33 Creating a Hot Spare Disk

4.4.3 Deleting a RAID Volume

Abstract

When a server no longer needs a **RAID** volume, you can delete the RAID volume to release the disk space.



Notice

The data that is lost during deletion of the RAID volume cannot be restored. Therefore, you must make sure that you have backed up important data before deleting the volume.


Prerequisite

A RAID volume is created successfully. For details, refer to “[4.2.2 Creating a RAID Volume](#)”.


Steps

1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 4-34](#).

Figure 4-34 List of Arrays Screen




2. Use the arrow keys to select the array where the RAID volume to be deleted is located, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 4-35](#).

Figure 4-35 List of Logical Drives Screen

3. Use the arrow keys to select the RAID volume to be deleted, and press **Delete**. A warning dialog box is displayed, see [Figure 4-36](#).

Figure 4-36 Warning Dialog Box

4. At the cursor in the warning dialog box, enter **Y** to delete the selected hot spare disk, see [Figure 4-37](#).

Figure 4-37 Deleting a RAID Volume

4.4.4 Deleting a Hot Spare Disk

Abstract


When the number of disks of a server cannot meet the requirements, you can delete an existing hot spare disk and restore it to a common disk.

Prerequisite


A hot spare disk is already created. For details, refer to "[4.4.2 Creating a Hot Spare Disk](#)".

Steps


1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 4-38](#).

Figure 4-38 List of Arrays Screen

2. Use the arrow keys to select the array where the hot spare disk to be deleted is located, and press **Delete**. The **Select Hotspare drives** screen is displayed, see [Figure 4-39](#).


Figure 4-39 Select Hotspare Drives Screen

3. Use the arrow keys to select the hot spare disk to be deleted, and then press **Insert** to add the disk to the **Selected Drives** list, see [Figure 4-40](#).


Figure 4-40 Selected Drives List**Note**

Press the **Delete** key to delete the selected disk from the **Selected Drives** list.

4. Press **Enter**. A confirmation dialog box is displayed, see [Figure 4-41](#).

Figure 4-41 Confirmation Dialog Box

5. At the cursor in the confirmation dialog box, enter **Y** to delete the selected hot spare disk, see [Figure 4-42](#).

Figure 4-42 Deleting a Hot Spare Disk

4.4.5 Locating a Disk


Abstract

After the indicator of a disk is lit, you can locate the disk so that you can easily replace or maintain it.

Steps


1. In the **Options** area on the **BIOS** configuration utility screen, use the arrow keys to select **Disk Utilities**, and then press **Enter**. The **Select Disks and press <Enter>** screen is displayed, see [Figure 4-43](#).

Figure 4-43 Select Disks and Press <Enter> Screen




2. Use the arrow keys to select the disk to be located, and then press **Enter**. A function menu is displayed, see [Figure 4-44](#).

Figure 4-44 Function Menu



3. Use the arrow keys to select **Identify Device**, and then press **Enter**. A prompt message is displayed, see [Figure 4-45](#). At this time, the status indicator of the hard disk is lit up solid blue.

Figure 4-45 Disk Indicator Lit

4. Press any key to go out the disk indicator. The disk locating ends.

4.4.6 Configuring a Pass-Through Disk

Abstract

When the mode of the ports of a SmartROC 3100 RAID controller card is set to **HBA**, the hard disks connected to these ports can be configured as pass-through disks.


Context

The port modes are described as follows:

- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.
- In mixed mode, the connected disks support both RAID and HBA mode.
 - The RAID mode is applicable to the disks that have been used to create a RAID volume.
 - The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.

Steps


1. In the **Options** area on the **BIOS** configuration utility screen, use the arrow keys to select **Controller Details**, and then press **Enter**. The controller details are displayed. The value of **Controller Mode** is **MIXED**, see [Figure 4-46](#).

Figure 4-46 Controller Details


2. Press **ESC** to return to the BIOS configuration screen. Use the arrow keys to select **Configure Controller Settings** and press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 4-47](#).

Figure 4-47 Configure Controller Settings Screen


3. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**. The **Configure Controller Port Mode** screen is displayed, see [Figure 4-48](#).

Figure 4-48 Configure Controller Port Mode Screen

4. Use the arrow keys to select the port whose connected disk is not used to create a RAID volume, and press **Enter**. In the displayed dialog box, set the port mode to **HBA**, see [Figure 4-49](#).


Figure 4-49 Setting the Port Mode to HBA

5. (Optional) If the connected disk is already used to create a RAID volume, set the port mode to **MIXED**, see [Figure 4-50](#).


Figure 4-50 Setting the Port Mode to MIXED**Note**

The mode of the ports whose connected disks are already used to create a RAID volume cannot be set to HBA.

6. Set the port mode as required, and then press **Esc** to exit. In the displayed dialog box, select **Yes** to save the configuration, see [Figure 4-51](#).

Figure 4-51 Saving the Configuration

7. Wait until a configuration success message is displayed, see [Figure 4-52](#).

Figure 4-52 Successful Configuration


8. Press **Esc** multiple times until the **Exit Utility** dialog box is displayed, see [Figure 4-53](#).

Figure 4-53 Exit Utility Dialog Box

9. In the **Exit Utility** dialog box, select **NO**, and then press **Enter**. The BIOS configuration utility screen is displayed, see [Figure 4-54](#).

Figure 4-54 BIOS Configuration Utility Screen

10. Use the arrow keys to select **Controller Details**, and then press **Enter**. The controller details are displayed, see [Figure 4-55](#). The value of **Controller Mode** is **HBA**.

Figure 4-55 Controller Details

4.4.7 Enabling the Caching Function

Abstract

A NETAŞ SmartROC 3100 RAID controller card supports the caching function. In legacy mode, a SmartROC 3100 RAID supports the following three caching modes:

- **IO Bypass**: valid only when a RAID logical volume is formed by **SSDs**.
- **Controller Cache**: enables controller cache optimization. The read cache and write cache are used at the same time.
- **None**: disables the controller cache. Neither **IO Bypass** nor **Controller Cache** is used. After you select **Controller Cache** mode, the caching function is enabled, which improves the data read/write speed.



Note

You can enable the caching function only by referring to this procedure. The caching function cannot be enabled on the Web portal of the **BMC**.

Prerequisite

A RAID volume is created successfully. For details, refer to "[4.2.2 Creating a RAID Volume](#)".

Context

Enabling the caching function improves the data read/write speed. The details are as follows:

- When a RAID controller card reads the data, if the data has been written into the Cache, the data can be directly read from the Cache to prevent the hard disk from searching for the data again, thus saving the response time and improving the data read speed.
- When a RAID controller card writes the data, the data is directly written into the Cache. The RAID controller card refreshes the data to the hard disk only when the written data is accumulated to a certain extent, achieving batch data write. In addition, the Cache is a fast read/ write device, so the read/write speed of the Cache is higher than that of the hard disk, thus improving the data write speed.




Note


To ensure the data security in the Cache, you can configure a super capacitor for the RAID controller card. In case of unexpected power failure of the server, the super capacitor is used to supply power, and provides data security protection in the Cache.

Steps


1. On the **Configuration Menu** screen, use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **List of Arrays** screen is displayed, see [Figure 4-56](#).

Figure 4-56 List of Arrays Screen


2. Use the arrow keys to select the array for which the caching function needs to be enabled, and then press **Enter**. The **List of Logical Drives** screen is displayed, see [Figure 4-57](#).

Figure 4-57 List of Logical Drives Screen

3. Press **Enter**. In the displayed **Logical Drive Details** dialog box, view the property information about the RAID volume, see [Figure 4-58](#). The value of **Acceleration Method** is **None**, indicating that the caching function is disabled.

Figure 4-58 Logical Drive Details Dialog Box

4. Press **Ctrl+C** to switch the caching mode. On the screen as shown in [Figure 4-59](#), the value of **Acceleration Method** becomes **Controller Cache**, indicating that the caching function is enabled.

Figure 4-59 Enabling the Caching Function

4.5 Common Configurations (UEFI Mode)

By using the **BIOS** configuration utility, you can configure and maintain a created **RAID** volume. For a description of the common operations on a SmartROC 3100 RAID controller card in **UEFI** mode, refer to [Table 4-9](#).

Table 4-9 Common Operations on a SmartROC 3100 RAID Controller Card

Common Operation	Description
Setting a port mode	Refer to " 4.5.1 Setting the Mode of a Port ".
Locating a disk	Refer to " 4.5.2 Locating a Disk ".
Creating a hot spare disk	Refer to " 4.5.3 Creating a Hot Spare Disk ".
Changing a hot spare disk	Refer to " 4.5.4 Changing a Hot Spare Disk ".
Deleting a hot spare disk	Refer to " 4.5.5 Deleting a Hot Spare Disk ".
Configuring a power mode	Refer to " 4.5.6 Configuring the Performance or Power Mode ".
Deleting a RAID volume	Refer to " 4.5.7 Deleting a RAID Volume ".
Deleting a disk group	Refer to " 4.5.8 Deleting a Disk Group ".
Clearing RAID configuration information	Refer to " 4.5.9 Clearing RAID Configuration Information ".
Configuring a pass-through disk	Refer to " 4.5.10 Configuring a Pass-Through Disk ".
Enabling the caching function	Refer to " 4.5.11 Enabling the Caching Function ".

4.5.1 Setting the Mode of a Port

Abstract

A SmartROC 3100 RAID controller card supports four port modes: RAID, HBA, mixed, and independent. Before adding the disk corresponding to a port to a RAID logical volume, you must check the port mode.

The SmartROC 3100 RAID controller card supports setting the port mode in the following two ways:

- Setting the mode of all ports
- Setting the mode of a single port

Context

The port modes are described as follows:

- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.

- In mixed mode, the connected disks support both RAID and HBA mode.
- The RAID mode is applicable to the disks that have been used to create a RAID volume.
- The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.
- In independent mode, each port can be set to the above three modes.

Steps

- Setting the Mode of All Ports


1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 4-60](#).

Figure 4-60 Configure Controller Settings Screen



2. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**.

The **Configure Controller Port Mode** screen is displayed, see [Figure 4-61](#).

Figure 4-61 Configure Controller Port Mode Screen

3. Use the arrow keys to select **Set Controller Port Mode**, and then press **Enter**. The **Set Controller Port Mode** dialog box is displayed, see [Figure 4-62](#).

Figure 4-62 Set Controller Port Mode Dialog Box

4. Use the arrow keys to select the port mode to be set, and then press **Enter**, see [Figure 4-63](#).

Figure 4-63 Selecting a Port Mode




5. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully, see [Figure 4-64](#).

Figure 4-64 Successful Setting

6. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.
- Setting the Mode of a Single Port
 1. Perform [Step 1](#) through [Step 3](#) in [Setting the Mode of All Ports](#). The **Set Controller Port Mode** dialog box is displayed, as shown in [Figure 4-65](#).

Figure 4-65 Set Controller Port Mode Dialog Box



2. Use the arrow keys to select **Independent**, and then press **Enter** to set the port mode to **Independent**.
3. Set the mode of each port in the port list as required.
4. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully.

4.5.2 Locating a Disk


Abstract

After the indicator of a disk is lit, you can locate the disk so that you can easily replace or maintain it. You can locate a physical disk or multiple disks in a disk group.


Steps

- Locating a Single Physical Disk


1. On the controller management screen, use the arrow keys to select **Disk Utilities**, and then press **Enter**. The screen for the list of physical disks mounted on the **RAID** controller card is displayed, see [Figure 4-66](#).

Figure 4-66 Screen for the List of Disks Mounted on the RAID Controller Card

2. Use the arrow keys to select the disk to be located, and then press **Enter**. The screen for setting a disk is displayed, see [Figure 4-67](#).

Figure 4-67 Setting a Disk


3. Use the arrow keys to select **Identify Device**, and then press **Enter**. The **Identify Device** screen is displayed, see [Figure 4-68](#).

Figure 4-68 Identify Device Screen

4. Next to **Identification Duration (seconds)**, enter the time of the lighting delay (unit: seconds), select **Yes**, and press **Enter** for confirmation, see [Figure 4-69](#).

Figure 4-69 Lighting Delay

5. Use the arrow keys to select **Start**, and then press **Enter**. The status indicator of the hard disk is lit (as shown in [Figure 4-70](#)) and keeps solid blue.

Figure 4-70 Starting Locating a Disk**Note**

The indicator flashing duration is the configured lighting delay. After the lighting delay is reached, the default value 86400 s (24 hours) is restored, and the indicator goes out.

6. (Optional) To go out the disk indicator and end the locating, press **Esc** to return to the locating screen, use the arrow keys to select **Stop**, and press **Enter**, see [Figure 4-71](#).


Figure 4-71 Ending Disk Locating

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.
- Locating Multiple Disks in a Disk Group
 1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-72](#).


Figure 4-72 Array Configuration Screen

2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-73](#).

Figure 4-73 Managing Arrays Screen



3. Use the arrow keys to select the array in which the disk to be located is placed, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-74](#).

Figure 4-74 Managing the Selected Array

4. Use the arrow keys to select **Identify Device**, and then press **Enter**. The **Identify Device** screen is displayed, see [Figure 4-75](#).

Figure 4-75 Identify Device Screen

5. Next to **Identification Duration (seconds)**, enter the time of the lighting delay (unit: seconds), and then press **Enter** for confirmation, see [Figure 4-76](#).

Figure 4-76 Lighting Delay

6. Use the arrow keys to select **Start**, and then press **Enter**. The status indicators of the member disks of the array are lit up solid blue (as shown in [Figure 4-77](#)).

Figure 4-77 Starting Locating a Disk

Note

The indicators of the hot spare disks belonging to the array are also lit and flash continuously at the same time. The indicator flashing duration is the configured lighting delay. After the lighting delay is reached, the default value 86400 s (24 hours) is restored, and the indicator goes out.

7. (Optional) To go out the disk indicator and end the locating, press **Esc** to return to the locating screen, and use the arrow keys to select **Stop**. The disk indicator goes out and the disk locating ends, see [Figure 4-78](#).

Figure 4-78 Ending Disk Locating

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.3 Creating a Hot Spare Disk

Abstract

A hot spare disk improves the data security of a [RAID](#) array. For a description of the hot spare disk types supported by a SmartROC 3100 [RAID](#) controller card, refer to [Table 4-10](#).

Table 4-10 Hot Spare Disk Types

Type	Description
Dedicated	<ul style="list-style-type: none"> ● This type of hot spare disks is exclusive to the specified one or more disk groups of a RAID controller card. One or more hot spare disks can be created for each disk group. ● When a disk in a disk group is faulty, a dedicated hot spare disk temporarily takes over the faulty disk.

Auto Replace	<ul style="list-style-type: none">● This type of hot spare disks provides the hot standby function for a disk group of a RAID controller card. One or more hot spare disks can be created for each disk group.● When a disk in a disk group is faulty, a hot spare disk of this type automatically replaces the faulty disk.
--------------	---

Prerequisite

There are sufficient idle disks on the server.

Context

When creating a hot spare disk, pay attention to the following points:

- Multiple hot spare disks can be created for a disk group, but only one type of hot spare disk can be set at a time. That is, either **Dedicated** or **Auto Replace** is specified.
- An idle disk can be set as a hot spare disk. The disk that has been used to create a RAID volume cannot be set as a hot spare disk.
- The hot spare disk must be of the same type as that of any member disk in the corresponding disk group. That is, all of them are **SATA** disks or **SAS** disks, and the hot spare disk's capacity must not be less than the maximum capacity of the member disks.
- Disk groups at all levels except RAID 0 support hot spare disks.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-79](#).


Figure 4-79 Array Configuration Screen

2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-80](#).

Figure 4-80 Managing Arrays Screen



3. Use the arrow keys to select the array for which you need to create the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-81](#).

Figure 4-81 Managing the Selected Array


4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 4-82](#).

Figure 4-82 Manage Spare Drives Screen

5. In accordance with your actual conditions, use the arrow keys to select the type of the hot spare disk to be created, and then press **Enter**. The screen for selecting a hot spare disk is displayed, see [Figure 4-83](#).

Figure 4-83 Selecting a Hot Spare Disk

6. Use the arrow keys to select the disk to be set as a hot spare disk, press **Enter**, and then set the status of the disk to **Enabled**, see [Figure 4-84](#).

Figure 4-84 Setting Disk Status

7. Use the arrow keys to select **Assign Dedicated Spare**, and then press **Enter**. The hot spare disk is successfully created, see [Figure 4-85](#).

Figure 4-85 Hot Spare Disk Created Successfully

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.4 Changing a Hot Spare Disk

Abstract

A SmartROC 3100 RAID controller card supports modifying the type of a hot spare disk, namely, allowing type change between **Dedicated** and **Auto Replace**.

Only one type of hot spare disk can be set at a time. That is, **Dedicated** and **Auto Replace** cannot be specified at the same time. This procedure uses changing a hot spare disk of the **Dedicated** type to that of the **Auto Replace** type as an example to describe how to perform a type change.



Note

A hot spare disk of the **Auto Replace** type can be changed to that of the **Dedicated** type by referring to this procedure.

Prerequisite

A hot spare disk is already set to the **Dedicated** type. For details, refer to “[4.5.3 Creating a Hot Spare Disk](#)”.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-86](#).


Figure 4-86 Array Configuration Screen



2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-87](#).

Figure 4-87 Managing Arrays Screen

3. Use the arrow keys to select the array for which you need to modify the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-88](#).

Figure 4-88 Managing the Selected Array

4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 4-89](#).

Figure 4-89 Manage Spare Drives Screen

5. Use the arrow keys to select **Change Spare type to AutoReplace**, and then press **Enter**.

The screen for hot spare disk type modification is displayed, see [Figure 4-90](#).

Figure 4-90 Screen for Hot Spare Disk Type Modification



6. Select **Submit Changes**, and then press **Enter**. The type of hot spare disk is changed successfully, see [Figure 4-91](#).

Figure 4-91 Hot Spare Disk Type Changed Successfully

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.5 Deleting a Hot Spare Disk

Abstract

When the number of disks of a server cannot meet the requirements, you can delete an existing hot spare disk and restore it to a common disk.

Prerequisite

A hot spare disk is created successfully. For details, refer to "[4.5.3 Creating a Hot Spare Disk](#)".


Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-92](#).


Figure 4-92 Array Configuration Screen




2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-93](#).

Figure 4-93 Managing Arrays Screen

3. Use the arrow keys to select the array for which you need to delete the hot spare disk, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-94](#).

Figure 4-94 Managing the Selected Array


4. Use the arrow keys to select **Manage Spare Drives**, and then press **Enter**. The **Manage Spare Drives** screen is displayed, see [Figure 4-95](#).

Figure 4-95 Manage Spare Drives Screen

5. Use the arrow keys to select **Delete Spare Drives**, and then press **Enter**. The screen for selecting a hot spare disk is displayed, see [Figure 4-96](#).

Figure 4-96 Selecting a Hot Spare Disk

6. Use the arrow keys to select the hot spare disk to be deleted, press **Enter**, and then set the status of the disk to **Enabled**, see [Figure 4-97](#).

Figure 4-97 Setting Disk Status

7. Use the arrow keys to select **Delete Spare Drives** and press **Enter**. The hot spare disk is deleted successfully, see [Figure 4-98](#).

Figure 4-98 Hot Spare Disk Deleted Successfully

8. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.6 Configuring the Performance or Power Mode

Abstract

This procedure describes how to configure a power mode for a SmartROC 3100 [RAID](#) controller card. For a description of the power modes supported by the SmartROC 3100 [RAID](#) controller card, refer to [Table 4-11](#).

Table 4-11 Power Supply Mode Descriptions


Power Mode	Description
Minimum Power	In this mode, the static settings of the power are adjusted to the possible lowest value, and the power is dynamically reduced based on the working load.
Balanced	In this mode, the static settings of the power are adjusted in accordance with the actual RAID configuration, and the power is dynamically reduced based on the working load.

Maximum Performance	In this mode, the static settings of the power are adjusted to the possible highest value, and the power is not dynamically reduced based on the working load.
---------------------	--

Steps

1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 4-99](#).

Figure 4-99 Configure Controller Settings Screen




2. Use the arrow keys to select **Manage Power Settings**, and then press **Enter**. The **Manage Power Settings** screen is displayed, see [Figure 4-100](#).

Figure 4-100 Manage Power Settings Screen

3. Use the arrow keys to select **Power Mode**, and then press **Enter**. The **Port Mode** menu is displayed, see [Figure 4-101](#).

Figure 4-101 Power Mode Menu

4. In accordance with your actual conditions, use the arrow keys to select the power mode to be applied, and then press **Enter** for confirmation, see [Figure 4-102](#).


Figure 4-102 Selecting a Power Mode

5. (Optional) Determine whether to enable **Survival Mode** as required.

**Note**


By default, **Survival Mode** is enabled, indicating that when the working temperature of the power supply exceeds the threshold, the RAID controller card is allowed to switch to the energy saving mode, but it may cause performance deterioration.

- a. Use the arrow keys to select **Survival Mode**, and then press **Enter**. The **Survival Mode** menu is displayed, see [Figure 4-103](#).


Figure 4-103 Survival Mode Menu

b. Use the arrow keys to select **Disabled**, and then press **Enter**. The **Survival Mode** is disabled, see [Figure 4-104](#).

Figure 4-104 Survival Mode Menu



6. Use the arrow keys to select **Submit Changes**, and press **Enter**. The power mode is set successfully, see [Figure 4-105](#).

Figure 4-105 Power Mode Configured Successfully

7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.7 Deleting a RAID Volume

Abstract

When a server no longer needs a **RAID** volume, you can delete the RAID volume to release the disk space.



Notice

- The data that is lost during deletion of the RAID volume cannot be restored. Therefore, you must make sure that you have backed up important data before deleting the volume.
- If the RAID logical volume to be deleted is the only logical volume on the current array, the array is also deleted after the RAID logical volume is deleted.

Prerequisite

The RAID volume is created successfully. For details, refer to "[4.3.2 Creating a RAID Volume](#)".

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-106](#).


Figure 4-106 Array Configuration Screen



2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-107](#).

Figure 4-107 Managing Arrays Screen

3. Use the arrow keys to select the array for which you need to delete a logical volume, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-108](#).

Figure 4-108 Managing the Selected Array


4. Use the arrow keys to select **List Logical Drives**, and then press **Enter**. The **List Logical Drives** screen is displayed, see [Figure 4-109](#).

Figure 4-109 List Logical Drives Screen

5. Use the arrow keys to select the logical volume to be deleted, and then press **Enter**. The screen for managing the selected logical volume is displayed, see [Figure 4-110](#).

Figure 4-110 Managing the Selected Logical Volume

6. (Optional) To view the details of the logical volume, use the arrow keys to select **Logical Drive Details**, and then press **Enter**, see [Figure 4-111](#).

Figure 4-111 Logical Volume Details

7. On the logical volume management screen, use the arrow keys to select **Delete Logical Drive**, and then press **Enter**. The confirmation screen for RAID volume deletion is displayed, see [Figure 4-112](#).

Figure 4-112 Confirmation Screen for RAID Volume Deletion

8. Select **Submit Changes**, and then press **Enter**. The logical volume is deleted successfully, see [Figure 4-113](#).

Figure 4-113 Logical Volume Deleted Successfully

9. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.8 Deleting a Disk Group

Abstract

When a server no longer needs a disk group (array), you can delete it to release the disk space.



Notice

- When an array is deleted, the **RAID** logical volume built on it is also deleted, and the data lost during the deletion cannot be restored. Therefore, it is required to make sure that you have backed up important data before the deletion.
- If the array to be deleted is the only array of the RAID controller card, the configurations related to the RAID controller card are also cleared, and the default configurations are restored.

Prerequisite

A RAID volume is created successfully to form a disk group. For details, refer to "[4.3.2 Creating a RAID Volume](#)".

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The **Array Configuration** screen is displayed, see [Figure 4-114](#).


Figure 4-114 Array Configuration Screen



2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The **Manage Arrays** screen is displayed, see [Figure 4-115](#).

Figure 4-115 Managing Arrays Screen

3. Use the arrow keys to select the array to be deleted, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-116](#).

Figure 4-116 Managing the Selected Array

4. Use the arrow keys to select **Delete Array**, and then press **Enter**. The **Delete Array** screen is displayed, see [Figure 4-117](#).

Figure 4-117 Delete Array Screen

5. Use the arrow keys to select **Submit Changes**, and press **Enter**. The array is deleted successfully, see [Figure 4-118](#).

Figure 4-118 Array Deleted Successfully

6. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.9 Clearing RAID Configuration Information

Abstract

This procedure describes how to clear all configuration information that is already created on a SmartROC 3100 [RAID](#) controller card.



Notice

The data that is lost during clearing of the configuration information on the RAID controller card cannot be restored. Therefore, it is required to make sure that you have backed up important data before the clearing operation.


Prerequisite

A RAID volume is created successfully and it has the corresponding RAID configuration information. For details, refer to “[4.3.2 Creating a RAID Volume](#)”.


Steps

1. On the controller management screen, use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 4-119](#).

Figure 4-119 Configure Controller Settings Screen



2. Use the arrow keys to select **Clear Configuration**, and then press **Enter**. The screen for clearing the configurations is displayed, see [Figure 4-120](#).

Figure 4-120 Clearing the Configurations

3. Use the arrow keys to select **Delete All Array Configuration**, and then press **Enter**. The screen for clearing the array configurations is displayed, see [Figure 4-121](#).

Figure 4-121 Clearing the Array Configurations

4. Use the arrow keys to select **Submit Changes**, and press **Enter**. The configuration information is cleared successfully, see [Figure 4-122](#).

Figure 4-122 Configuration Cleared Successfully

5. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen.

4.5.10 Configuring a Pass-Through Disk

Abstract

When the mode of the ports of a SmartROC 3100 **RAID** controller card is set to **HBA**, the hard disks connected to these ports can be configured as pass-through disks.

Context

Port modes include RAID, HBA and Mixed, which are described as follows:


- In RAID mode, the connected disks can be used only after they form a RAID volume.
- In HBA mode, the connected disks are pass-through disks and cannot be used to create a RAID volume. Instead, they can only be used directly.
- In mixed mode, the connected disks support both RAID and HBA mode.
 - The RAID mode is applicable to the disks that have been used to create a RAID volume.
 - The HBA mode (pass-through) is applicable to the disks that are not used to create a RAID volume.

- In independent mode, each port is allowed to use any of the above three modes.


Steps

1. On the controller management screen, use the arrow keys to select **Controller Information**, and then press **Enter**. The **Controller Information** screen is displayed. The value of **Controller Mode** is **RAID**, see [Figure 4-123](#).


[Figure 4-123 Controller Information Screen](#)



2. Press **Esc** to return to the controller management screen. Use the arrow keys to select **Configure Controller Settings**, and then press **Enter**. The **Configure Controller Settings** screen is displayed, see [Figure 4-124](#).


Figure 4-124 Configure Controller Settings Screen

3. Use the arrow keys to select **Configure Controller Port Mode**, and then press **Enter**. The screen for setting the port mode is displayed, see [Figure 4-125](#).


Figure 4-125 Setting the Port Mode

4. Use the arrow keys to select **Set Controller Port Mode**, and then press **Enter**. The **Set Controller Port Mode** dialog box is displayed, see [Figure 4-126](#).

Figure 4-126 Set Controller Port Mode Dialog Box



5. Use the arrow keys to select **HBA**, and then press **Enter**. The mode of all ports is set to **HBA**, see [Figure 4-127](#).


Figure 4-127 Setting the Port Mode to HBA

6. Use the arrow keys to select **Submit Changes**, and press **Enter**. The port mode is set successfully, see [Figure 4-128](#).


Figure 4-128 Port Mode Set Successfully



7. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen, see [Figure 4-129](#).

Figure 4-129 Controller Management Page

8. Use the arrow keys to select **Controller Details**, and then press **Enter**. On the displayed **Controller Information** screen, view the port mode after the modification, see [Figure 4-130](#). The value of **Controller Mode** is **HBA**.

Figure 4-130 Controller Information Screen

4.5.11 Enabling the Caching Function

Abstract

A NETAŞ SmartROC 3100 RAID controller card supports the caching function. In UEFI mode, a SmartROC 3100 RAID supports the following two caching modes:

- Controller Cache: enables controller cache optimization. The read cache and write cache are used at the same time.
- None: disables the controller cache.

After you select the **Controller Cache** mode, the caching function is enabled, which improves the data read/write speed.



Note

You can enable the caching function only by referring to this procedure. The caching function cannot be enabled on the Web portal of the BMC.

Prerequisite

A RAID volume is created successfully. For details, refer to “[3.3.2 Creating a RAID Volume](#)”.

Context

Enabling the caching function improves the data read/write speed. The details are as follows:

- When a RAID controller card reads the data, if the data has been written into the Cache, the data can be directly read from the Cache to prevent the hard disk from searching for the data again, thus saving the response time and improving the data read speed.
- When a RAID controller card writes the data, the data is directly written into the Cache. The RAID controller card refreshes the data to the hard disk only when the written data is accumulated to a certain extent, achieving batch data write. In addition, the Cache is a fast read/ write device, so the read/write speed of the Cache is higher than that of the hard disk, thus improving the data write speed.



Note

To ensure the data security in the Cache, you can configure a super capacitor for the RAID controller card. In case of unexpected power failure of the server, the super capacitor is used to supply power, and provides data security protection in the Cache.

Steps


1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The screen for configuring an array is displayed, see [Figure 4-131](#).

Figure 4-131 Configuring an Array

2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The screen for managing arrays is displayed, see [Figure 4-132](#).

Figure 4-132 Managing Arrays

3. Use the arrow keys to select the array for which the caching function needs to be enabled, and then press **Enter**. The screen for managing the selected array is displayed, see [Figure 4-133](#).

Figure 4-133 Managing the Selected Array


4. Use the arrow keys to select **List Logical Drives**, and then press **Enter**. The screen for managing RAID logical volumes is displayed, see [Figure 4-134](#).

Figure 4-134 Managing Logical Volumes

5. Use the arrow keys to select the RAID logical volume for which the caching function needs to be enabled, and then press **Enter**. The screen for managing the selected RAID logical volume is displayed, see [Figure 4-135](#).

Figure 4-135 Managing the Selected Logical Volume


6. Use the arrow keys to select **Logical Drive Details**, and press **Enter**. The RAID volume information is displayed, see [Figure 4-136](#). The value of **Acceleration Method** is **None**, indicating that the caching function is disabled.

Figure 4-136 Viewing RAID Volume Information

7. Press **Esc** to return to the RAID volume management screen. Use the arrow keys to select **Edit Logical Drive** and press **Enter**. The screen for setting RAID volume information is displayed, see [Figure 4-137](#).

Figure 4-137 Setting RAID Volume Information

8. Use the arrow keys to select **Acceleration Method**, and then press **Enter**. The **Acceleration Method** dialog box is displayed, see [Figure 4-138](#).

Figure 4-138 Acceleration Method Dialog Box

There is no **I/O Bypass** option in **Acceleration Method** when **HDDs** are used. The **Acceleration Method** dialog box is displayed based on the actual hard disk configuration.


9. Use the arrow keys to select **Controller Cache**, and then press **Enter**. The caching mode is set to **Controller Cache**, see [Figure 4-139](#).

Figure 4-139 Setting the Caching Mode

10. Use the arrow keys to select **Submit Changes**, and press **Enter**. The caching mode is set successfully, see [Figure 4-140](#).


Figure 4-140 Caching Mode Set Successfully

11. Select **Back to Main Menu**, and then press **Enter** to return to the controller management screen, see [Figure 4-141](#).

Figure 4-141 Managing the Controller

12. Repeat [Step 1](#) through [Step 6](#). The RAID volume information is displayed, see [Figure 4-142](#).

The value of **Acceleration Method** is **Controller Cache**, indicating that the caching function is enabled.

Figure 4-142 Viewing RAID Volume Information

4.6 Typical Scenarios for Replacing a Disk (Legacy Mode)

For a description of the common scenarios for replacing a disk in a RAID volume on a SmartROC 3100 RAID card in legacy mode, refer to [Table 4-12](#).

Table 4-12 Common Scenarios for Replacing a Disk in a RAID Volume on a SmartROC 3100 RAID Controller Card

Scenario	Description
Scenario 1	A newly inserted disk is converted into a RAID member disk. For details, refer to " 4.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk ".
Scenario 2	After a faulty SmartROC 3100 RAID card is replaced, all the member disks in the RAID 1 array managed by the original faulty RAID card are moved to a new RAID card. For details, refer to " 4.6.2 Moving All Member Disks of a RAID 1 Volume ".

4.6.1 Converting a Newly Inserted Disk Into a RAID Member Disk

Abstract

To convert a newly inserted disk into a RAID member disk, perform the following operations:

- The newly inserted disk is a foreign disk.
- The disk in a slot is removed and inserted back.

Inserting a Foreign Disk as a New Disk

When a disk in a RAID volume created on a server is faulty and needs replacement, remove the faulty disk from the disk slot on the server, and insert the prepared disk into the disk slot of the faulty disk.

After the disk is replaced, the configuration utility of the RAID controller card automatically synchronizes data on the newly inserted disk in the RAID volume.



Note

Data is automatically synchronized to the newly inserted disk no matter whether it carries RAID information or not.

Installing a Disk in the Original Slot After Removing It from the Slot

After a disk on a server is used to create a RAID volume, if the disk is removed from its slot and then inserted back, the RAID controller card configuration utility automatically rebuild the disk.



Note

The RAID 0 volume does not support the above functions.

4.6.2 Moving All Member Disks of a RAID 1 Volume

Abstract

If a SmartROC 3100 [RAID](#) controller card on a server fails and needs to be replaced, all the member disks in the RAID 1 on the faulty RAID controller card need to be moved to a new SmartROC 3100 RAID controller card.



Notice

It is risky to move the member disks of the RAID volume, and therefore it is recommended that you contact NETAŞ technical support for help.

Steps

1. Shut down the server, and replace the faulty SmartROC 3100 RAID controller card with a new one.
2. Connect all member disks of the RAID 1 be moved to the new SmartROC 3100 RAID controller card.
3. Power on the server again and start the server system.

4. Start the BIOS configuration utility. For details, refer to “[4.2.1 Starting the Configuration Utility](#)”.
5. Query RAID volume information. For details, refer to “[4.4.1 Querying RAID Volume Information](#)”.
6. Contact NETAŞ technical support to move member disks.

4.7 Typical Scenarios for Replacing a Disk (UEFI Mode)

For a description of the common scenarios for replacing a disk in a RAID volume on a SmartROC 3100 RAID card in UEFI mode, refer to [Table 4-13](#).

Table 4-13 Common Scenarios for Replacing Disks in a RAID Volume on a SmartROC 3100 RAID Controller Card

Scenario	Description
Scenario 1	When a RAID 0 member disk is faulty, the RAID controller card is reconfigured. For details, refer to “ 4.7.1 A RAID 0 Member Disk Fails ”.
Scenario 2	When a member disk of a logical volume with no hot spare disk configured is faulty, the faulty disk is replaced. For details, refer to “ 4.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails ”.
Scenario 3	When a member disk of a logical volume with a hot spare disk configured is faulty, the faulty disk is replaced. For details, refer to “ 4.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails ”.

4.7.1 A RAID 0 Member Disk Fails

RAID 0 does not support data redundancy or backup. As a result, data cannot be restored after a fault occurs in the RAID 0 logical volume. It is necessary to install a new disk and reconfigure RAID.

4.7.2 A Member Disk of a RAID Redundant Logical Volume (Without a Configured Hot Spare Disk) Fails

Abstract

If a fault occurs in a member disk of a redundant logical volume (with no hot spare disk configured) on a SmartROC 3100 RAID controller card, the SmartROC 3100 RAID controller card can automatically restore the data after the faulty disk is replaced with a new disk. During the process, the member disk status may be **OK**, but the logical disk status may be **Failed**. In this case, you need to restore the logical disk status.

Steps

1. On the controller management screen, use the arrow keys to select **Array Configuration**, and then press **Enter**. The screen for configuring an array is displayed.
2. Use the arrow keys to select **Manage Arrays**, and then press **Enter**. The screen for managing arrays is displayed.
3. Use the arrow keys to select the array for which you need to manage the logical volume, and then press **Enter**. The screen for managing the selected array is displayed.
4. Use the arrow keys to select **List Logical Drives**, and then press **Enter**. The screen for managing logical volumes is displayed.
5. Use the arrow keys to select the logical volume to be corrected, and then press **Enter**. The screen for managing the selected logical volume is displayed.
6. Use the arrow keys to select **Re-Enable Logical Drive**, and then press **Enter**. The screen for restoring logical volume status is displayed.
7. Press **Enter**. The status of the logical disk is restored.

Verification

On the logical volume management screen, use arrow keys to select **Logical Drive Details**, and then press **Enter**. The logical volume details are displayed. Verify that the logical volume status is **Ok**.

4.7.3 A Member Disk of a RAID Redundant Logical Volume (with a Configured Hot Spare Disk) Fails

When a fault occurs in a member disk of a redundant logical volume (with a hot spare disk configured) on a SmartROC 3100 **RAID** controller card, the RAID controller card automatically replaces the faulty disk with the hot spare disk and restores the data.

- When the hot spare disk is of the **Dedicated** type, the RAID controller card temporarily replaces the faulty disk with the hot spare disk and automatically restores the data. After the faulty disk is replaced with a new disk, the hot spare disk is restored to Hot Spare status.
- When the hot spare disk is of the **Auto Replace** type, the RAID controller card immediately replaces the faulty disk with the hot spare disk and automatically restores the data. After the new disk is inserted, the new disk becomes a hot spare disk.

Chapter 5

Appendices

Table of Contents

ARCCONF CLI Tool.....	277
Common Operations.....	307

5.1 ARCCONF CLI Tool

During the proper operation of a server, the ARCCONF **CLI** tool allows you to configure a **RAID** controller card without restarting the server.

5.1.1 Downloading and Installing the ARCCONF Tool

Abstract

Before using the ARCCONF tool to operate a **RAID** controller card, you must download and install the ARCCONF tool.

Steps

Downloading the ARCCONF Tool

1. On the address bar of the browser on the maintenance **PC**, enter <https://enterprise.NETAS.com.cn/tools-detail.html?id=9>, and then press **Enter**. The page for downloading the tool is displayed.
2. Click the latest version. The page for downloading it is displayed.



Note

For example, the filename of the downloaded tool is "*LogTool_V01.20.01.02.zip*," where "V01.20.01.02" is the tool version number and vary with the update of the tool version.

This manual uses the tool of the *LogTool_V01.20.01.02.zip* version as an example to describe how to download and install the ARCCONF tool.

3. Click . The latest version of the tool is downloaded to the maintenance PC.

Installing the ARCCONF Tool

4. Decompress the *LogTool_V01.20.01.02.zip* tool package to the *LogTool_V01.20.01.02* folder, and then enter this folder.

5. Depending on the server operating system, perform the following operations:

If...	Then...
The OS is Linux	<ol style="list-style-type: none"> Decompress the <i>LogCollect_linux.tar.gz</i> package in the <i>LogTool_V01.20.01.02</i> folder to the <i>LogCollect_linux</i> folder. Access the <i>LogCollect_linux\components\raid\tools</i> directory. <i>Arcconf-linux</i> in the <i>tools</i> folder is the ARCCONF tool. Connect the maintenance PC to the server directly through a network cable, and upload the <i>arcconf-linux</i> file to any directory of the server OS through the SSH tool on the maintenance PC. Rename the <i>arcconf-linux</i> file as <i>arcconf</i>. Grant the executable permission to the <i>arcconf</i> files.
The OS is Windows	<ol style="list-style-type: none"> Decompress the <i>LogCollect_windows.7z</i> package in the <i>LogTool_V01.20.01.02</i> folder to the <i>LogCollect_windows</i> folder. Access the <i>LogCollect_windows\components\raid\tools\x86_64</i> directory. <i>Arcconf64.exe</i> in the <i>x86_64</i> folder is the ARCCONF tool. On the maintenance PC, upload the <i>arcconf64.exe</i> file to the <i>C:\Windows\System32</i> directory of the server OS through the SSH tool. Rename the <i>arcconf64.exe</i> file as <i>arcconf.exe</i>.
The OS is VMware	<ol style="list-style-type: none"> Use a file transfer tool (for example, Putty) to upload the tool package applicable to VMware to any directory of the server OS. The following uses <i>/tmp</i> as an example. Run the following command to install the ARCCONF tool: <code>esxcli software vib install -v=/tmp/vmware-esx-provider-arcconf.vib --no-sig-check</code> In the above command, <i>/tmp/vmware-esx-provider-arcconf.vib</i> must be the complete path of the ARCCONF tool file. Enter the <i>/opt/pmc</i> (installation path of the ARCCONF tool) directory and execute the commands related to the RAID controller card.




If the OS is Linux, the ARCCONF tool can be used only after the executable permission is granted to it. The following command is used to grant the highest permission. You must exercise caution when executing the following command: `# chmod 777 arcconf`

5.1.2 Common Commands

When you configure a RAID controller card by using the ARCCONF CLI tool, it is recommended that you comply with the initial configuration flow shown in [Figure 5-1](#).

Figure 5-1 Initial Configuration Flow



Note

- The ID of a queried RAID controller card is used as a parameter for executing other common commands. For the commands, refer to [“5.1.2.1 Querying the Basic Information About a RAID Controller Card”](#).
- The queried available disks and disk slots are used as the parameters of the RAID creation command. For the command, refer to [“5.1.2.6 Creating and Deleting a RAID Array”](#).
- A RAID volume is set as the first boot device. For the command, refer to [“5.1.2.7 Setting a Boot Device”](#).

5.1.2.1 Querying the Basic Information About a RAID Controller Card

Command Function

This command displays all the RAID controller cards identified by the ARCCONF tool or the basic information about the specified RAID controller card.

Syntax

- `arcconf list`

- `arcconf list [Controller#]`

Syntax Description

Parameter	Description	Setting
<code><Controller#></code>	ID of a RAID controller card	-

Usage Guidelines

None

Example

- The following example shows how to query the IDs of all RAID controller cards identified by the ARCCONF tool:

```
# arcconf list
Controllers found: 1
-----
Controller information
-----
Controller ID      : Status, Slot, Mode, Name, SerialNumber, WWN
Controller 1:      : Optimal, Slot 0, RAID (Hide RAW), ZTE Adaptec SmartIOC2100 SDPSx V2.0, 7193 [REDACTED], 50123456789ABC00
Command completed successfully.
```

For a description of the fields in the command output, refer to [Table 5-1](#).

Table 5-1 Descriptions of the Fields in the Command Output

Field	Description
Controller ID	ID of a RAID controller card
Status	Status of a RAID controller card
Slot	Slot number of a RAID controller card
Mode	Work mode of a RAID controller card

- The following example shows how to query information about RAID controller card 1:

```
# arcconf list 1
```

```

Controllers found: 1
Controller information
  Controller ID : Status, Slot, Mode, Name, SerialNumber, WWN
  Controller 1   : Optimal, Slot 0, RAID (Hide RAW), ZTE Adaptec SmartIO2100 SDP5x V2.0, 7109 [REDACTED], 50123456789ABC00

Array Information
  Array ID      : Status (Interface, TotalSize MB, FreeSpace MB)
  Array 0       : Ok (SATA SSD, 457228 MB, 0 MB)
  Array 1       : Ok (SATA SSD, 3662336 MB, 0 MB)

Logical device information
  Logical ID    : Status (RAID, Interface, Size MB) Name
  Logical 0     : Optimal (0, Data, 457300 MB) system
  Logical 1     : Optimal (1, Data, 1831388 MB) test

Physical device information
  Physical ID   : State (Interface, BlockSize, SizeMB, Vendor, Model, Type) WWN, [Location]
  Physical 0,0   : Ready (SATA, 512 Bytes, 13351930MB, ATA , ST1400NM0003-2T, Hard Drive) 30123456789ABC02, [Enclosure Direct Attached, Slot 0(Connector 0:CN0)]
  Physical 0,1   : Ready (SATA, 512 Bytes, 13351930MB, ATA , ST1400NM0003-2T, Hard Drive) 30123456789ABC03, [Enclosure Direct Attached, Slot 1(Connector 0:CN1)]
  Physical 0,2   : Ready (SATA, 512 Bytes, 13351930MB, ATA , ST1400NM0003-2T, Hard Drive) 30123456789ABC04, [Enclosure Direct Attached, Slot 2(Connector 0:CN2)]
  Physical 0,4   : Online (SATA, 512 Bytes, 1831420MB, ATA , SAMSUNG MZ7L31T0, Solid State Drive) 30123456789ABC06, [Enclosure Direct Attached, Slot 4(Connector 1:CN1)]
  Physical 0,5   : Online (SATA, 512 Bytes, 1831420MB, ATA , SAMSUNG MZ7L31T0, Solid State Drive) 30123456789ABC07, [Enclosure Direct Attached, Slot 5(Connector 1:CN1)]
  Physical 0,6   : Ready (SATA, 512 Bytes, 1831420MB, ATA , SAMSUNG MZ7L31T0, Solid State Drive) 30123456789ABC05, [Enclosure Direct Attached, Slot 6(Connector 1:CN1)]
  Physical 0,7   : Ready (SATA, 512 Bytes, 1831420MB, ATA , SAMSUNG MZ7L31T0, Solid State Drive) 30123456789ABC08, [Enclosure Direct Attached, Slot 7(Connector 1:CN1)]
  Physical 0,17  : Online (SATA, 512 Bytes, 457862MB, ATA , INTEL SSDSC2KB40, Solid State Drive) 30123456789ABC11, [Enclosure Direct Attached, Slot 17(Connector 4:CN4)]
  Physical 2,3   : Ready (SES2, Not Applicable, Not Applicable, ZTE , Virtual SGPIO, Enclosure Services Device) 50123456789ABC12, [Not Applicable]

```

For a description of the fields in the command output, refer to [Table 5-2](#).

Table 5-2 Descriptions of the Fields in the Command Output

Field	Description
Array ID	ID of the disk array
Logical ID	ID of the virtual disk
Physical ID	ID of the physical disk

5.1.2.2 Querying the Detailed Information About a RAID Controller Card

Command Function

This command displays detailed information about a [RAID](#) controller card, disk array, virtual disk, and physical disk.

Syntax

```
arcconf getconfig <Controller#> [AD | LD [LD#] | AR [AR#] | PD [Channel# ID# Channel# ID#...]]|  
MC | CN | [AL]] [nologs]
```

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
AD	Specifies that RAID controller card attributes are queried	-
LD	Specifies that virtual disk attributes are queried	-

[LD#]	ID of a virtual disk	-
[AR#]	ID of a disk array	-
PD	Specifies that physical disk attributes are queried	-
<Channel# ID#>	Channel ID (slot number) of a disk	-
MC	Specifies that the maximum cache information is queried	-
CN	Specifies that the RAID controller card information is queried	-
[AL]	Specifies that all device information is queried	-

Usage Guidelines

None

Example

- The following example shows how to query the information about a RAID controller card:

```
# arcconf getconfig 1 ad
```

```

Controllers found: 1
-----
Controller information
-----
Controller Status : Optimal
Controller Mode : RAID (Hide RAW)
Channel description : SCSI
Controller Model : ZTE Adaptec SmartIOC2100 SDPSx V2.0
Controller Serial Number : 71934[REDACTED]
Controller World Wide Name : 50123456789ABC00
Physical Slot : 0
Temperature : 46 C/ 114 F (Normal)
Host bus type : PCIe 3.0
Host bus speed : 7880 MBps
Host bus link width : 8 bit(s)/link(s)
PCI Address (Bus:Device:Function) : 0:3c:0:0
Number of Ports : 5
Internal Port Count : 5
External Port Count : 0
Defunct disk drive count : 0
NCQ status : Enabled
Queue Depth : Automatic
Monitor and Performance Delay : 60 minutes
Elevator Sort : Enabled
Degraded Mode Performance Optimization : Disabled
Latency : Disabled
Statistics data collection mode : Disabled
Post Prompt Timeout : 15 seconds
Boot Controller : False
Primary Boot Volume : None
Secondary Boot Volume : None
Driver Name : smartpqi
Driver Supports SSD I/O Bypass : Yes
Manufacturing Part Number : Not Applicable
Manufacturing Spare Part Number : Not Applicable
Manufacturing Wellness Log : Not Applicable
NVRAM Checksum Status : Passed
Sanitize Lock Setting : None
-----
Power Settings
-----
Power Consumption : Not Available
Current Power Mode : Maximum Performance
Pending Power Mode : Not Applicable
Survival Mode : Enabled
-----
I2C Settings
-----
I2C Address : 0x0
-----
Cache Properties
-----

```

```

-----  

Physical Drive Write Cache Policy Information  

-----  

Configured Drives : Default  

Unconfigured Drives : Default  

HBA Drives : Default  

-----  

RAID Properties  

-----  

Logical devices/Failed/Degraded : 2/0/0  

Automatic Failover : Disabled  

Background consistency check : High  

Consistency Check Delay : 0 seconds  

Parallel Consistency Check Supported : Enabled  

Parallel Consistency Check Count : 1  

Inconsistency Repair Policy : Disabled  

Consistency Check Inconsistency Notify : Disabled  

Rebuild Priority : Medium  

Expand Priority : Medium  

-----  

Controller Version Information  

-----  

Firmware : 2.66[0]  

Driver : Linux 1.1.4-115  

Hardware Revision : A  

-----  

Temperature Sensors Information  

-----  

Sensor ID : 0  

Current Value : 37 deg C  

Max Value Since Powered On : 46 deg C  

Location : Inlet Ambient  

Sensor ID : 1  

Current Value : 46 deg C  

Max Value Since Powered On : 56 deg C  

Location : ASIC
-----  


```

For a description of the fields in the command output, refer to [Table 5-3](#).

Table 5-3 Descriptions of the Fields in the Command Output

Field	Description
Controller Status	Status of the RAID controller card
Controller Mode	Work mode of the RAID controller card

Controller Model	Model of the RAID controller card
Field	Description
Firmware	Firmware version of the RAID controller card
Driver	Driver version of the RAID controller card

- The following example shows how to query the information about array 1: # arcconf getconfig 1 ar 1

```
Controllers found: 1
-----
Array Information
-----
Array Number 1
  Name : B
  Status : Ok
  Interface : SATA SSD
  Total Size : 3662336 MB
  Unused Size : 0 MB
  Block Size : 512 Bytes
  Array Utilization : 100.00% Used, 0.00% Unused
  Type : Data
  Transformation Status : Not Applicable
  Spare Rebuild Mode : Dedicated
  SSD I/O Bypass : Enabled
-----
Array Logical Device Information
-----
Logical 1 : Optimal (1, Data, 1831388 MB) test
-----
Array Physical Device Information
-----
```

- The following example shows how to query the information about virtual disk 1:

```
# arcconf getconfig 1 ld
Controllers found: 1
-----
Logical device information
-----
Logical Device number 0
  Logical Device name : system
  Disk Name : /dev/sdd
  Block Size of member drives : 512 Bytes
  Array : 0
  RAID level : 1
  Status of Logical Device : Optimal
  Size : 457830 MB
  Stripe-unit size : 256 KB
  Full Stripe Size : 256 KB
  Interface Type : SATA SSD
  Device Type : Data
  Boot Type : None
  Heads : 255
  Sectors Per Track : 32
  Cylinders : 65535
  Caching : Enabled
  Mount Points : /boot/efi 200 MB  Partition Number 1 /boot 1024 MB  Partition Number 2
  LD Acceleration Method : Controller Cache
  Volume Unique Identifier : 600508B1001C1FF69AB000FC028B878C
-----
Array Physical Device Information
-----
Device 16 : Present (457862MB, SATA, SSD, Channel:0, Device:16) PHYS7295
Device 17 : Present (457862MB, SATA, SSD, Channel:0, Device:17) BTHC450
```

For a description of the fields in the output displayed after the command for querying virtual disk 1 is executed, refer to [Table 5-4](#).

Table 5-4 Description of the Fields in the Command Output

Parameter	Description
Logical Device name	Name of the virtual disk
Disk Name	Drive letter of the virtual disk
Array	ID of the virtual disk
RAID level	RAID level
Status of Logical Device	RAID status
Boot Type	Boot type of the virtual disk
Caching	Whether cache is enabled

- The following example shows how to query the information about the disk in slot 5:

```
# arcconf getconfig 1 pd 0 5
```

```
Controllers found: 1
-----
Physical Device information
-----
Device #0
  Device is a Hard drive
  State : Online
  Drive has stale RIS data : False
  Block Size : 512 Bytes
  Physical Block Size : 4K Bytes
  Transfer Speed : SATA 6.0 Gb/s
  Reported Channel,Device(T:L) : 0,5(5:0)
  Reported Location : Enclosure Direct Attached, Slot 5(Connector 1:CN1)
  Array : 1
  Vendor : ATA
```

5.1.2.3 Querying Virtual Disk Information

Command Function

This command displays virtual disk information.

Syntax

```
arcconf getconfig <Controller#> LD [LD#]
```

Syntax Description

Parameter	Description	Range
<Controller#>	ID of the RAID controller card that the disks are connected to	-

LD	Specifies that virtual disk attributes are queried	-
[LD#]	ID of a virtual disk	-

Usage Guidelines

None

Example

The following example shows how to display the information about all virtual disks in RAID controller card 1:

```
# arcconf getconfig 1 ld
```

```
Controllers found: 1
-----
Logical device information
-----
Logical Device number 0
  Logical Device name          : system
  Disk Name                   : /dev/sdd
  Block Size of member drives : 512 Bytes
  Array                       : 0
  RAID level                  : 1
  Status of Logical Device   : Optimal
  Size                        : 457830 MB
  Stripe-unit size           : 256 KB
  Full Stripe Size           : 256 KB
  Interface Type              : SATA SSD
  Device Type                 : Data
  Boot Type                   : None
  Heads                       : 255
  Sectors Per Track          : 32
  Cylinders                   : 65535
  Caching                      : Enabled
  Mount Points                : /boot/efi 200 MB  Partition Number 1 /boot 1024 MB  Partition Number 2
  LD Acceleration Method      : Controller Cache
  Volume Unique Identifier    : 600508B1001C1FF69AB000FC028B878C
-----
Array Physical Device Information
-----
Device 16                   : Present (457862MB, SATA, SSD, Channel:0, Device:16) PHYS7295
Device 17                   : Present (457862MB, SATA, SSD, Channel:0, Device:17) BTHC450
```

For a description of the fields in the command output, refer to [Table 5-5](#).

Table 5-5 Descriptions of the Fields in the Command Output

Field	Description
Logical Device name	Name of the virtual disk
Disk Name	Drive letter of the virtual disk
Array	ID of the virtual disk
RAID level	RAID level of the virtual disk
Status of Logical Device	RAID status
Boot Type	Boot type of the virtual disk
Caching	Whether the caching function is enabled

5.1.2.4 Querying Physical Disk Information

Command Function

This command displays physical disk information.

Syntax

arcconf getconfig <Controller#> PD [Channel# ID# Channel# ID#...]

Syntax Description

Parameter	Description	Range
<Controller#>	ID of the RAID controller card that the disks are connected to	-
PD	Specifies that physical disk attributes are queried	-
<Channel# ID#>	Channel ID (slot number) of a physical disk	-

Usage Guidelines

None

Example

The following example shows how to display the information about the physical disk in slot 5:

```
# arcconf getconfig 1 pd 0 5
```

```
Controllers found: 1
-----
Physical Device information
-----
Device #0
  Device is a Hard drive
  State : Online
  Drive has stale RIS data : False
  Block Size : 512 Bytes
  Physical Block Size : 4K Bytes
  Transfer Speed : SATA 6.0 Gb/s
  Reported Channel,Device(T:L) : 0,5(5:0)
  Reported Location : Enclosure Direct Attached, Slot 5(Connector 1:CN1)
  Array : 1
  Vendor : ATA
```

5.1.2.5 Querying the Firmware/Driver Version of a RAID Controller Card

Command Function

This command displays the firmware/driver version of a [RAID](#) controller card.

Syntax

arcconf getversion [Controller#]

Syntax Description

Parameter	Description	Setting
[Controller#]	ID of a RAID controller card	-

Usage Guidelines

None

Example

The following example shows how to query the firmware/driver version of the RAID controller card whose ID is 1:

```
# arcconf getversion 1
Controllers found: 1
Controller #1
=====
Firmware : 2.66[0] (0)
Driver   : Linux 1.1.4-115 (0)

Command completed successfully.
```

For a description of the fields in the command output, refer to [Table 5-6](#).

Table 5-6 Descriptions of the Fields in the Command Output

Field	Description
Firmware	Firmware version of the RAID controller card
Driver	Driver version of the RAID controller card

5.1.2.6 Creating and Deleting a RAID Array

Command Function

The following commands create and delete a [RAID](#) array.

Syntax

- arcconf create <Controller#> logicaldrive [Options] <Size> <RAID#> <Channel# ID#> [Channel# ID#] ... [noprompt] [nologs]
- arcconf delete <Controller#> logicaldrive <Id#> [noprompt] [nologs]

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
[Options]	Options for creating a RAID array	<ul style="list-style-type: none">stripesize: optional, specifying the stripe size in KB, range: 16, 32, 64, 128*, 256, 512, 1024.legs: optional parameter, specifying the number of sub-logical devices.

Parameter	Description	Setting
		<ul style="list-style-type: none"> ● name: optional, used to specify the name of the logical disk. ● method: initialization method of the logical device. Valid options include BUILD and DEFAULT. ● wcache: write cache setting of the logical device. Valid options include WT and WB. ● ldcache: sets the cache of the logical device. Valid options include LON and LOFF. ● ssdoverprovisioningoptimization <enable disable>: specifies the initialization to support the fast parity check function. ● cachelinesize: specifies the size of the maximum cache. The default value is 64.
<Size>	Logical device size (MB). You can set it to all available space by using the MAX keyword.	-
<RAID#>	RAID level	RAID 0, RAID 1, RAID 1ADM, RAID 10, RAID 10ADM, RAID 5, RAID 6, RAID 50, RAID 60
<Channel# ID#>	Channel ID (slot number) of a disk	-
<Id#>	ID of a virtual disk	-

Usage Guidelines

By default, the disks without data are used to create a RAID array.

Example

- The following example shows how to query available disks. In the command output, the disk whose **State** is **Ready** can be used to create a RAID array, and the disk whose **State** is **Online** has been used to create a RAID array.

```
# arcconf getconfig 1 pd
```

```
Controllers found: 1
-----
Physical Device information
-----
Channel #0:
Device #0
  Device is a Hard drive
  State : Online
  Drive has stale RIS data : False
  Block Size : 512 Bytes
  Physical Block Size : 4K Bytes
  Transfer Speed : SATA 6.0 Gb/s
  Reported Channel,Device(T:L) : 0,0(0:0)
  Reported Location : Direct Attached, Slot 0(Connector 0:CN0)
  Array
  Vendor
  Model : Micron_5300_MTFD
  Firmware : D3MU001
  Serial number : 21022CAF0844
  World-wide name : 30015EBE03050E41
  Reserved Size : 32768 KB
  Used Size : 457830 MB
  Unused Size : 0 MB
  Total Size : 457862 MB
  Write Cache : Disabled (write-through)
  S.M.A.R.T. : No
  S.M.A.R.T. warnings : 0
  SSD : Yes
  Device On Boot Connector : No
  NCQ supported : Supported
  NCQ status : Enabled
  Boot Type : None
  Current Temperature : 28 deg C
  Maximum Temperature : 47 deg C
  Threshold Temperature : 70 deg C
  PHY Count : 1
  Drive Configuration Type : Data
  Drive Exposed to OS : False
  Sanitize Erase Support : True
  Sanitize Lock Freeze Support : True
  Sanitize Lock Anti-Freeze Support : True
  Sanitize Lock Setting : None
  Usage Remaining : 100 percent
  Estimated Life Remaining : Not Applicable
  SSD Smart Trip Wearout : False
  56 Day Warning Present : False
  Drive Unique ID : 6C0D214B7B889236EEB49804E39D9427
  Drive SKU Number : Not Applicable
```

- The following example shows how to create RAID 1:

```
# arccfg create 1 logicaldrive stripesize 64 name test max 1 0 4 0 5
Controllers found: 1
Do you want to add a logical device to the configuration?
Press y, then ENTER to continue or press ENTER to abort: y
Creating logical device: test
Command completed successfully.
```

- The following example shows how to delete the virtual disk whose ID is 1: # arccfg delete 1 logicaldrive 1

```
Controllers found: 1
WARNING: Deleting this logical device will automatically delete array 1 because it is the only logical device present on that array.
All data in logical device 1 will be lost.
Delete the logical device?
Press y, then ENTER to continue or press ENTER to abort: y
Deleting: logical device 1 ("test")
Command completed successfully.
```

5.1.2.7 Setting a Boot Device

Command Function

The following two commands set a RAID volume or physical disk as a boot device.

- The configuration takes effect when the work mode of a RAID volume on a RAID controller card is mixed or RAID.
- The configuration takes effect when the work mode of a physical disk on a **RAID** controller card is **HBA** or mixed.

Syntax

- `arcconf setboot <Controller#> logicaldrive <LogicalDrive#> type <Boot Type>`
- `arcconf setboot <Controller#> device <Channel# ID#> type <Boot Type>`

Syntax Description

Parameter	Description	Setting
<code><Controller#></code>	ID of a RAID controller card	-
<code><LogicalDrive#></code>	ID of a virtual disk	-
<code><Boot Type></code>	Boot order	<ul style="list-style-type: none"> • Primary: sets the virtual disk or physical disk as the primary boot device. • Secondary: sets the virtual disk or physical disk as the secondary boot device.
<code><Channel# ID#></code>	ID of a physical disk	-

Usage Guidelines

None

Example

- The following example shows how to set virtual disk 0 as the primary boot device:

```
# arcconf setboot 1 logicaldrive 0 type Primary
Controllers found: 1
Do you wish to change the boot type of the selected device.
Press y, then ENTER to continue or press ENTER to abort: y

Command completed successfully.
```

- The following example shows how to set the disk in slot 6 as the secondary boot device:

```
# arcconf setboot 1 device 0 6 type Secondary
```

```
Controllers found: 1
Do you wish to change the boot type of the selected device.
Press y, then ENTER to continue or press ENTER to abort: y

Command completed successfully.
```

5.1.2.8 Setting a Hot Spare Disk

Command Function

This command sets a global or dedicated hot spare disk.

Syntax

```
arcconf setstate <Controller#> device <Channel# ID#> <State> [ARRAY <AR#> [AR#] ... ]
[SPARETYPE <TYPE>] [noprompt] [nologs]
```

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
<Channel# ID#>	Channel ID (slot number) of a disk	-
<State>	Adds or deletes a hot spare disk	<ul style="list-style-type: none"> • HSP: adds a hot spare disk for one or more arrays • RDY: deletes a hot spare disk
[ARRAY <AR#> [AR#] ...]	ID of a virtual disk	-
[SPARETYPE <TYPE>]	Sets the replacement mode of the hot spare disk	<ul style="list-style-type: none"> • 1: dedicated spare, which can be shared between arrays • 2: automatically replaced but cannot be shared between arrays

Usage Guidelines

None

Example

- The following example shows how to set the disk in slot 6 as a dedicated hot spare disk:


```
# arcconf setstate 1 device 0 6 hsp array 1 sparetype 2
```

```
Controllers found: 1
Any existing hot-spare drives of a different sparettype will be removed.
Command completed successfully.
```

- The following example shows how to cancel the disk in slot 6 as a dedicated hot spare disk:

```
# arcconf setstate 1 device 0 6 rdy
```

```
Controllers found: 1
Command completed successfully.
```

5.1.2.9 Setting the Work Mode of a RAID Controller Card

Command Function

This command sets the work mode of a RAID controller card.

Syntax

```
arcconf setcontrollermode <Controller#> <Controller Mode>
```

Syntax Descriptions

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
<Controller Mode>	Work mode of the RAID controller card	<ul style="list-style-type: none"> • 2: indicates HBA mode. This mode does not allow RAID array creation. All hard disks are reported to the OS as raw disks. • 3: indicates RAID mode. The RAID controller card only reports the disks that form a RAID array to the OS. • 5: indicates Mixed mode. The RAID controller card reports that the RAID disks that form a RAID array. If a disk has no RAID configuration information, the RAID controller card reports to the OS as a raw disk. <p>The OS can directly operate the disk.</p>

Usage Guidelines

None

Example

- The following example shows how to set the work mode of a RAID controller card to RAID:

```
# arcconf setcontrollermode 1 3
Controllers found: 1
Command completed successfully.
```

- The following example shows how to query the work mode of a RAID controller card: # arcconf getconfig 1

```
Controllers found: 1
-----
Controller information
-----
Controller Status : Optimal
Controller Mode : RAID (Hide RAW)
Channel description : SCSI
Controller Model : ZTE Adaptec SmartIOC2100 SDPSx V2.0
```

5.1.2.10 Setting the Read/Write Cache Ratio of a RAID Controller Card

Command Function

This command sets the respective percentage of the read cache and write cache of a RAID controller card.

Syntax

arcconf setcache <Controller#> cacheratio read write

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
read	Percentage of the read cache	0–100
write	Percentage of the write cache	0–100

Usage Guidelines

The sum of the percentage of the read cache and that of the write cache is 100%.

Example

The following example shows how to set the percentage of the read cache to 50% and that of the write cache to 50%:

```
# arcconf setcache 1 cacheratio 50 50
```

```
Controllers found: 1 Command

completed successfully.
```

5.1.2.11 Setting the Caching Policy

Command Function

This command enables or disables the caching function for a virtual disk.

Syntax

- `arcconf setcache <Controller#> logicaldrive <LogicalDrive#> con`
- `arcconf setcache <Controller#> logicaldrive <LogicalDrive#> coff`

Syntax Description

Parameter	Description	Range
<code><Controller#></code>	ID of a RAID controller card	-
<code><LogicalDrive#></code>	ID of a virtual disk	-

Usage Guidelines

None

Example

- The following example shows how to enable the caching function for virtual disk 0:

```
# arcconf setcache 1 logicaldrive 0 con
```

```
Controllers found: 1 Cache mode is already set to Enabled.
```

```
Command aborted.
```

- The following example shows how to disable the caching function for virtual disk 0:

```
# arcconf setcache 1 logicaldrive 0 coff
```

```
Controllers found: 1
```

```
Command completed successfully.
```

5.1.2.12 Using Cache Without a Capacitor

Command Function

This command enables the use of the cache of a RAID controller card without a capacitor.



Notice

If the cache of the RAID controller card is used when there is no capacitor, data may be lost if the RAID controller card is powered off. Therefore, you must use this command with caution.

Syntax

```
arcconf setcache <Controller#> nobatterywritecache enable
```

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-

Usage Guidelines

None

Example

The following example shows how to enable the use of the cache of a RAID controller card without a capacitor:

```
# arcconf setcache 1 nobatterywritecache enable
```

```
Controllers found: 1 WARNING : Enabling write caching on a cache module without a
fully charged battery or capacitor could cause data loss in the event of a power
failure.
```

```
Are you sure you want to continue? Press y, then ENTER to
continue or press ENTER to abort: y Command completed
successfully.
```

5.1.2.13 Setting a Disk as a Pass-Through Disk**Command Function**

After a disk is set as a pass-through disk, the **OS** can directly manage it.

Syntax

```
arcconf uninit <Controller#> [Channel# ID#] ... [nologs]
```

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-

[Channel# ID#]	Channel ID (slot number) of a disk	-
----------------	------------------------------------	---

Usage Guidelines

None

Example

The following example shows how to set the disk in slot 5 as a pass-through disk:

```
# arcconf uninit 1 0 5
```

```
Controllers found: 1
Uninitializing Channel 0, Device 5.

Command completed successfully.
```

5.1.2.14 Querying and Setting the Write Cache Policy for Disks

Command Function

The following commands query and set the write cache policy for disks.

Syntax

- arcconf getconfig <Controller#> logicaldrive ad
- arcconf setcache <Controller#> drivewritecachepolicy <drivetype> <cachepolicy> <drivetype> <cachepolicy>...

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
<drivetype>	Type of disk for which you want to set the write cache policy	<ul style="list-style-type: none"> Configured: sets the write cache policy for RAID member disks in RAID or mixed mode. Unconfigured: sets the write cache policy for non-RAID member disks in RAID or mixed mode. HBA: set the write cache policy for disks in HBA mode.
<cachepolicy>	Write cache policy	<ul style="list-style-type: none"> 0: Default (keeps the default status) 1: Enabled (enables write caching) 2: Disabled (disables write caching)

Usage Guidelines

None

Example

- The following example shows how to set the write cache policy for disks in **Configured** status to **Enabled** and set the write cache policy for disks in **Unconfigured** status to **Disabled**:

```
# arcconf setcache 1 drivewritecachepolicy Configured 1 Unconfigured 2
```

```
Controllers found: 1 Enabling controller drive write cache can increase write
performance but risks losing the data in the cache on sudden loss.

Command completed successfully.
```

- The following example shows how to query the write cache policy for disks: # arcconf getconfig 1 ad

```
Controllers found: 1 -----
---

Controller information -----
-----

Controller Statue : Optimal
Controller Mode : Mixed
Channel description : SCSI

...
-

Physical Drive Write Cache Policy Information -----
-----

Configured Drives : Enabled
Unconfigured Drives : Disabled
HBA Drives : Default
...
```

5.1.2.15 Setting the Status of a Disk Locating Indicator

Command Function

This command turns on or off a disk locating indicator.

Syntax

- arcconf identify <Controller#> all [TIME <BlinkTime>] [STOP] [nologs]
- arcconf identify <Controller#> logicaldrive <logicaldrive#> [TIME <BlinkTime>] [nologs]
- arcconf identify <Controller#> device <Channel# ID#> [TIME <BlinkTime>] [nologs]

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
[TIME <BlinkTime>]	Time period (in seconds) that the locating indicator is lit for	-
[STOP]	Specifies that the locating indicator is off	-
<LogicalDrive#>	ID of a virtual disk	-
<Channel# ID#>	Channel ID (slot number) of a physical disk	-

Usage Guidelines

None

Example

- The following example shows how to light the locating indicators of disks in RAID group 1 for 5 seconds:

```
# arcconf identify 1 logicaldrive 1 time 5
Controllers found: 1
Only devices managed by an enclosure processor may be identified
Command completed successfully.
```

- The following example shows how to light the locating indicators of disks in slot 7 for 30 seconds:

```
# arcconf identify 1 device 0 7 time 30
Controllers found: 1
Only devices managed by an enclosure processor may be identified
Command completed successfully.
```

- The following example shows how to turn off the locating indicators of disks in all slots:

```
# arcconf identify 1 all stop
Controllers found: 1
No devices are blinking.

Command aborted.
```

5.1.2.16 Modifying the RAID Stripe Size

Command Function

This command modifies the RAID stripe size.

Syntax

```
arccconf modify <Controller#> from <LogicalDrive#> to stripesize <STRIPE> <Size> <RAID#>
<Channel# ID#> [Channel# ID#] ... [noprompt] [nologs]
```

Syntax Description

Parameter	Description	Range
<Controller#>	ID of a RAID controller card.	-
<LogicalDrive#>	ID of the virtual disk to be set.	-
<STRIPE>	Stripe size to be set.	16, 32, 64, 128, 256, 512, and 1024. Unit: KB.
<Size>	Size of the virtual disk. The max parameter can be used to specify all the available space of the virtual disk.	Unit: MB.
<RAID#>	RAID level of the virtual disk.	-
<Channel# ID#> [Channel# ID#]	Channel ID (slot number) of the virtual disk.	-

Usage Guidelines

- The **noprompt** parameter is used in the command to indicate forcible execution.
- If the **nologs** parameter is specified, this command is not executed when data is stored in the virtual disk.
- The stripe size and RAID capacity cannot be modified at the same time.
- When the RAID capacity is set to the maximum value and the stripe size needs to be modified, the **max** parameter cannot be used in the command to represent a number.



Note

For example, the **Changing the size and the stripe size simultaneously is not allowed** message is displayed if the following command is executed to modify the stripe size:

```
# arccconf modify 1 from 1 to stripesize 256 max 0 0 3
```

The following command can be executed to modify the stripe size:
 # arconf modify 1 from 1 to stripesize 256 915683 0 0 3

Example

The following example shows how to modify the stripe size to 128 KB without adding any hard disk:

```
# arconf modify 1 from1 to stripesize 128 1831388 1 0 4 0 5
```

```
Controllers found: 1
Reconfiguration of a logical device is a long process. Are you sure you want to continue?
Press y, then ENTER to continue or press ENTER to abort: y
Reconfiguring logical device: test
Command completed successfully.
```

5.1.2.17 Setting the Initialization Function for a Physical Disk

Command Function

The following two commands set the initialization function for a physical disk and query the task status of the physical disk.

Syntax

- arconf task start <Controller#> device <Channel# ID#> <task> [PATTERN <erasePattern>][noprompt]
- arconf task stop <Controller#> device <Channel# ID#>

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
<Channel# ID#>	Channel ID (slot number) of a disk	-
<task>	Task type	secureerase: securely erases disk data

[PATTERN <erasePattern>]	Initialization type	<ul style="list-style-type: none"> 1: zero initialization, which initializes all blocks as zero 2: random zero initialization, which randomly initializes blocks as zero 2: random zero initialization, which randomly initializes blocks as zero 4: enables the physical devices (HDDs and SSDs) to change the encryption key to prevent correct decryption of previously stored information. 5: block erasing and clearing method, applicable to SSDs only
Parameter	Description	Setting
		<ul style="list-style-type: none"> 6: overwrites user data with specific pattern data, applicable to HDDs only

Usage Guidelines

Because the command uses the **noprompt** parameter to indicate forcible execution, which omits the reconfirmation operation during the setting process. Therefore, the **noprompt** parameter is not recommended.

Example

- The following example shows how to initialize the disk in slot 5:

```
# arcconf task start 1 device 0 5 secureerase
Controllers found: 1
Secure erase of a Hard drive is a long process.
Warning: Rebooting the machine would stop the Secure erase task.

Are you sure you want to continue?
Press y, then ENTER to continue or press ENTER to abort: y

Secure Erasing Channel 0, Device 5.

command completed successfully.
[root@localhost home]#
```

- The following example shows how to query task status: # arcconf getstatus 1

```

Controllers found: 1
Physical Device Task:
  Channel,Device      : 0,5
  Task ID             : 100
  Current operation   : Secure Erase(Zero)
  Status               : In Progress
  Priority             : High
  Percentage complete : 0

Command completed successfully.
[root@localhost home]# █

```

5.1.2.18 Setting the Priority of a Background Task

Command Function

This command sets and applies the priority of a background task.

Syntax

- `arcconf setpriority <Controller#> priority [current]`
- `arcconf setpriority <Controller#> [Task ID#] <New Priority> [current]`

Syntax Description

Parameter	Description	Setting
<code><Controller#></code>	ID of a RAID controller card	-
<code>[Task ID#]</code>	Task type	<ul style="list-style-type: none"> • rebuild: rebuild • expand: expansion
<code><New Priority></code>	Task priority	<ul style="list-style-type: none"> • high: high priority • medium: medium priority • low: low priority

Usage Guidelines

None

Example

The following example shows how to set and apply the priority of a background rebuild task to medium:

```
# arcconf setpriority 1 rebuild medium
```

```
Controllers found: 1
Command completed successfully.
[root@localhost home]#
```

5.1.2.19 Querying Disk Array Rebuild Status

Command Function

This command queries the rebuild status of disk arrays on a [RAID](#) controller card.

Syntax

```
arcconf getstatus [Controller#]
```

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-

Usage Guidelines

None

Example

The following example shows how to query the rebuild status of disk arrays on RAID controller card 1:

```
# arconf getstatus 1
Controllers found: 1
Logical Device Task:
  Logical Device : 1
  Task ID       : 100
  Current operation : Rebuild
  Status         : In Progress
  Priority       : Medium
  Percentage complete : 94
```

Command completed successfully.

For a description of the fields in the command output, refer to [Table 5-7](#).

Table 5-7 Description of the Fields in the Command Output

Field	Description
Logical Device	ID of the virtual disk
Current operation	Current operation
Status	Status
Priority	Priority
Percentage complete	Completion percentage

5.1.2.20 Setting Consistency Check Status

Command Function

This command enables the consistency check function.

Syntax

arcconf consistencycheck <Controller#> <On [Delay]|Off> [noprompt] [nologs]

Syntax Description

Parameter	Description	Setting
<Controller#>	ID of a RAID controller card	-
<On [Delay] Off>	Consistency check status	<ul style="list-style-type: none"> on: enabled off: disabled

Usage Guidelines

None

Example

The following example shows how to enable the automatic consistency check function:

```
# arcconf consistencycheck 1 on
```

```
Controllers found: 1

Command completed successfully.
```

5.1.2.21 Upgrading Firmware

Command Function

This command upgrades the firmware of a [RAID](#) controller card.

Syntax

arcconf romupdate controller_id fwfile

Syntax Description

Parameter	Description	Setting
controller_id	ID of a RAID controller card	-
fwfile	Name of the .bin file required for firmware upgrade	-

Usage Guidelines

None

Example

The following example shows how to upgrade the firmware of a RAID controller card:

```
# arcconf romupdate 1 SmartFWx100.bin
```

```
Controllers found: 1

Are you sure you want to continue? Press y, then ENTER
to continue or press ENTER to abort: y

Updating controller 1 firmware...
Succeeded You must restart the system for firmware updates to
take effect.

Command completed successfully.
```

5.1.2.22 Collecting Firmware Logs

Command Function

This command collects firmware logs of a [RAID](#) controller card.

Syntax

```
arcconf savesupportarchive
```

Syntax Description

None

Usage Guidelines

None

Example

The following example shows how to collect firmware logs of a RAID controller card:

```
# arcconf savesupportarchive
```

```
Controllers found: 1

Usage: SAVESUPPORTARCHIVE [Path] [Firmware|GUI|Arcconf|Storlib|Basecode|Redfish]
Example: SAVESUPPORTARCHIVE C:\Adaptec\maxView Firmware Example:
SAVESUPPORTARCHIVE /var/log/maxView Storlib
Example: SAVESUPPORTARCHIVE Example: SAVESUPPORTARCHIVE .
=====
Saves all the logs
Path : directory other than default
```

```
Firmware      : saves Firmware logs
GUI          : saves GUI logs
Arcconf      : saves Arcconf logs
StorLib       : saves StorLib logs
Basecode      : saves Basecode logs
Redfish       : saves Redfish logs

The path is not specified, Using the default. The logs are saved in relevant folders in
/var/log/Support

Command completed successfully.
```

5.2 Common Operations

5.2.1 Setting the Boot Mode to Legacy

Abstract

You can set the boot mode of **BIOS** to **Legacy** in accordance with the actual operation requirements.

Prerequisite

The operation terminal is already connected to the real-time desktop of the server through the remote console of the management software.

Steps



Notice


Restarting the server may cause system service interruption.

1. Restart the server. The screen as shown in [Figure 5-2](#) is displayed.


Figure 5-2 BIOS Restart Screen



2. During the **POST** process, press **F2/DEL** as prompted. The BIOS configuration utility is started, see [Figure 5-3](#).

Figure 5-3 BIOS Configuration Utility Screen

3. Use arrow keys to select **Boot > Boot option filter**, and then press **Enter**. The **Boot option filter** dialog box is displayed, see [Figure 5-4](#).

Figure 5-4 Boot Option Filter Dialog Box

4. Use the arrow keys to select **Legacy only**, and then press **Enter** to set the boot mode of the BIOS to **Legacy**, see [Figure 5-5](#).

Figure 5-5 Setting the Boot Mode to Legacy

5. Press **F4** or use the arrow keys to select **Save & Exit > Save Changes and Exit**, and then press **Enter**. The **Save & Exit Setup** dialog box is displayed, see [Figure 5-6](#).

Figure 5-6 Save & Exit Setup Dialog

6. Use the arrow keys to select **Yes**, and press **Enter**. The boot mode is set to **Legacy**, and the server is restarted automatically.

5.2.2 Setting the Boot Mode to UEFI

Abstract

You can set the boot mode of **BIOS** to **UEFI** in accordance with the actual operation requirements.

Prerequisite

The operation terminal is already connected to the real-time desktop of the server through the remote console of the management software.

Steps



Notice


Restarting the server may cause system service interruption.

1. Restart the server. The screen as shown in [Figure 5-7](#) is displayed.


[Figure 5-7 BIOS Restart Screen](#)




2. During the [POST](#) process, press **F2/DEL** as prompted. The BIOS configuration utility is started, see [Figure 5-8](#).

Figure 5-8 BIOS Configuration Utility Screen

3. Use arrow keys to select **Boot > Boot option filter**, and then press **Enter**. The **Boot option filter** dialog box is displayed, see [Figure 5-9](#).

Figure 5-9 Boot Option Filter Dialog Box

4. Use the arrow keys to select **UEFI only**, and then press **Enter** to set the boot mode of the BIOS to **UEFI**, see [Figure 5-10](#).

Figure 5-10 Setting the Boot Mode to UEFI

5. Press **F4** or use the arrow keys to select **Save & Exit > Save Changes and Exit**, and then press **Enter**. The **Save & Exit Setup** dialog box is displayed, see [Figure 5-11](#).

Figure 5-11 Save & Exit Setup Dialog

6. Use the arrow keys to select **Yes**, and press **Enter**. The boot mode is set to **UEFI**, and the server is restarted automatically.

Glossary

BBU

- Battery Backup Unit

BIOS

- Basic Input/Output System

BMC

- Baseboard Management Controller

CLI

- Command Line Interface

CPU

- Central Processing Unit

CRC

- Cyclic Redundancy Check

DG

- Disk Group

HBA

- Host Bus Adapter

HDD

- Hard Disk Drive

I/O

- Input/Output

ID

- Identification

IO

- Input & Output

JBOD

- Just a Bunch of Disk

LD

- Logical Disk

NAS

- Network Attached Storage

OS

- Operating System

BIOS

- Basic Input/Output System

PC

- Personal Computer

PCIe

- Peripheral Component Interconnect Express

PMC

- PCI Mezzanine Card

POST

- Power-On Self-Test

RAID

- Redundant Array of Independent Disks

SAS

- Serial Attached SCSI

SATA

- Serial ATA

SSD

- Solid State Drive

SSH

- Secure Shell

UEFI

- Unified Extensible Firmware Interface

VD

- Virtual Drive

VRROC

- Virtual RAID on CPU

NETAS

- Zhongxing Telecommunications Equipment